Instruction manual Type:		Pump controller : S-No.:		
System controller for pumps with frequency converter, contactor or		MAR/MARH Software Version 1.03 Stand 23.12. Soft starter	.2014	
MARH Execution:	Image: State of the state	MAR Execution: pressure control pressure switch limits level control		
	level switch temperature controller temperature switch Fire mode Data Logger Modbus 485 RTU	level switch temperature contro temperature switch Fire mode	oller h	
Option:	GSM	Option: GSM		

<u>con</u>	tent	<u>page</u>
1.	Safety Precautions	2
2.	General / Mode of Operation	3
3.	Installation and Mounting	4
4.	Wiring and Connections / GSM - Wiring	4
5.	panel Description	7
6.	Programming instructions / operation / startup messages	9
7.	Display / operational messages	11
8.	Operating Indicators / Main Menu / Setup	12
9.	Trip history monitor /Troubleshooting	30
10.	Expert mode /MODbus and SMS	34
11.	Clear presentation of the menu structure	39
12.	customer settings	42

1. Safety Precautions

Before installing and commissioning of the frequency converter controller, please read the product manual carefully and observe all warnings and safety instructions. Keep this manual is always easily accessible in the vicinity of the frequency converter controller.

Definition of Information



Warning !

Disregarding the safety severe to fatal injuries can occur or considerable material damage!



Caution!

Failure to follow these instructions severe to fatal injuries can occur or considerable material damage!



Notice!

Failure to follow these instructions may result in malfunction of the system!

Warning!

The drive controller contains dangerous voltages and controls potentially dangerous rotating mechanical parts. The installation, commissioning and maintenance of this equipment should be performed only by qualified personnel who are familiar with the operation. The installation, commissioning and maintenance of this equipment should be performed only by qualified personnel who are familiar with the operation.

Do you have particular caution if the automatic restart is activated. To avoid injury by possibly unintentional restart of the drive controller after a power failure, turn off the automatic restart in case of doubt. When repairing or servicing this equipment, make sure that the system can not be switched on by others again! The frequency controller have DC link capacitors, which carry hazardous voltage even after the mains supply is switched off. Therefore, always wait after switching off the mains voltage for at least 5 minutes before working on the machine or turn on the unit again. It is important to ensure that no live parts are touched when power is applied or the intermediate circuit capacitors are charged.

Do not work on the wiring and check any signals when power is applied.

The Inverter - Regulator has a leakage current.

Ground the frequency controller on the connections provided.

The customer-supplied GFCI should be in the Inverter - Regulator **universal current sensitive** / selective RCD (FI) - Circuit breaker type: B, B + be with rated current 300mA.

Caution! An RCD (FI) - switch can not work sometimes in certain plants (eg long cable).

t is recommended that the frequency converter - controllers separately fused.

Make sure that the input voltage of the registered on the nameplate voltage.

Caution!

All frequency controllers are tested for dielectric strength and insulation resistance. Before the insulation measurement in the pump station, for example within the scope of the inspection frequency controller must be disconnected!

It is strongly recommended that all electrical equipment conforms to the National Electrical Codes and local regulations.

Factors such as high temperatures, high humidity as well as dust, dirt and corrosive gases. The installation should be a well-ventilated, not exposed to direct sunlight place.

Put them no mains voltage to the transducer terminals or to the control terminals. Enter the operating signals Hand/0/Auto via the selector switch on or about the driving of external contacts and not by switching on and off of a line or motor contactor. It is strongly recommended that all electrical equipment conforms to the National Electrical Codes and local regulations. Only qualified personnel should perform installation, alignment and maintenance. The manufacturer reserves the right to alter the technical data in order to make improvements or update information.

As these provisions are handled differently, the user must observe the respectively valid for Him requirements. The manufacturer can not release you from the obligation to comply with the latest safety standards the user.

Notice!

The technical data and descriptions in this guide are correct to the best knowledge and belief. Technical improvements have been continuously carried out - that's why the manufacturer reserves the right, without prior notice to carry out such changes. The manufacturer can not be held liable for errors in the manual.

Warranty is within Germany and within the

incorporated statutory warranty period and applies only to the product itself and not for any consequential loss or damage or costs associated with the occurrence of a Warranty claim arise at other plants or plant parts. The operator

shall, in each case to ensure that a failure or defect in the product can not lead to further damage.

2. General / Mode of Operation

2.1 MAR.... Pressure Control System

Congratulations on purchasing this high-quality pump control. This product complies with the latest technology and is continually developed and improved. The device was subjected to the production of an extensive examination and therefore functions properly. To read to ensure optimal function and observe these operating instructions.

This frequency inverter controller operates as an automatic pressure regulator, tested.

The speed of the pump (s) will be adjusted continuously. The actual pressure in the system is determined by pressure transducer (sensor). A PI controller regulates the pressure by analogy.

The pressure regulator is programmable and can be adapted to the respective operating conditions. The parameters are displayed on the display in plain text. Commissioning is menu driven. During commissioning, some data must be entered to ensure the smooth operation of the pumping plant. An adjustment of specific parameters (expert mode) requires special knowledge of pump technology. This should be done by a competent person or the manufacturer.

2.2 Benefits of speed control:

- almost constant pressure
- Continuous adjustment of pump power to the changing operating conditions
- Energy saving
- no large pressure vessel longer required
- low mechanical wear of pumps and maintenance free

2.3 Principles of speed control

To operate a speed control can be accurately and effectively, the following points to consider::

- the pump (s) must be construed in accordance with the plant / Requirement
- the pump (s) shall have power reserves available (80..90%) = system reserve capacity at rating
- Submersible Pumps in the frequency or operating range between 30. .99 (200) Hz should be restricted (hydrodynamic bearing)
- with submersible pumps must be based on an output reduction of about 5. .10%

2.4 Construction of a pressure control system

Non-return valve preventer is imperative and must be in the pressure behind the Pump will be installed! The expansion tank is to be fitted if required.



1 Flow direction 2 Controller 3 Motor 4 Pump

Example 1 pump System

Example 2 pumps System

5 Non-return valve

7 Pressure vessel

6 Pressure Transducer





2.5 Note for the operation of the system with Pressure vessel!

If the plant is operated with a pressure vessel, the vessel must be pre-pressed in normally state. The pre-squeezing pressure should be checked regularly. The amount of pre-squeezing pressure is: Start pressure bar minus 0.50.

e.g.:	Nominal System Pressure:	4.00 bar
-	Vessel Air Pressure:	3.50 bar

2.6 Booster Sets



Booster units are ready plumbed and wired pump installations. For them, the installation cost is minimal - connect to the existing network of pipes, mains and commissioning. The regulator is factory set at these facilities. This manual refers only to the electrical control of the system is therefore possibly the pump consult the manual (s) note the / partition. See manufacturers data sheet.

3. Installation and Mounting



Environmental conditions such as high temperatures, high humidity should be avoided as well as dust, dirt and corrosive gases. The installation should be a well-ventilated and not exposed to direct sunlight location.



Because of convection, the frequency control during installation of at least Be installed 15 cm from side walls or other facilities.

Warning!

The allowable temperature range of +5 ° C to +30 ° C must not be under-or exceeded Do not install the Inverter controller near heat-radiating bodies

3.1 Mounting the MAR.... Controller

Metal box: In the rear contains holes for wall mounting of the cabinet. The sole assembly recommended hung stud to the electrical cabinet. Mounting Dimensions: See manufacturers data sheet MAR- **Compact box:** In the rear there are 4 holes with d = 7 mm for wall mounting the switch box. Mounting Dimensions: See manufacturers data sheet MAR-

4. Wiring and Connections



Make sure that the input voltage corresponds to the nameplate voltage registered.



Be sure to supply voltage and terminal assignment instructions!

The installation, commissioning and maintenance of the actuators may be of an expert who is familiar with the pump system will be implemented.

Caution!

Shielded cables use! Screen to the grounding clamps in the cabinet and connected to the pump! For submersible pumps combine the screen with a ground potential in the vicinity of the pump. **Do they no mains power to the sensor - or control terminals.**



No manipulation of the sensor signal to make! No other users connect to the 24V supply!

The used pressure sensor (0. .10 V) or (4. .20 mA), is connected to the respective terminals!

Notice!

The respective pin assignment, refer to the respective diagram.

In systems with several pumps are used again and 0. .10 V sensors.

Here you can optionally one or more sensors are connected.

The respective pin assignment, refer to the respective diagram.

If the motor cable longer than 150 meters, it is advisable to install an motor reactor.. Verify the correct connection of the network, sensor, and control lines.

Caution!

4.1 Motor Protection

The MA Frequency control has a monitoring function for the motor current.

This motor current is set via the EDR-1 display. A special version of PTC thermistor to monitor the temperature can be used. This monitoring is set via the EDR-1 display.

The fixed pumps can have with overload relays or motor circuit breakers, a soft starter or contactor.

This motor current must be set on each engine protection. See the manufacturer's instructions.

Motor protection (such as Siemens)



3RW40 soft starter (such as Siemens)



4.2 Connection of inputs / outputs

In the lower portion of the cabinet MAR ... is the terminal strip.



The line to the pump, the sensor cable and wires for the external contacts must be provided with shielded cable and are connected to the adjacent principle with the grounding clamps. Expose The shielding and fasten by means of the grounding clamp on rail. Only with proper installation of the screen trouble-free operation is guaranteed!

4.3 Terminals

Connection to the mains, Fault relay, signal relay (option) External inputs (option) External outputs (option), sensor (s), pump (s), they look at the diagram or schematic or the terminal screen of the respective controller.

<u>4.4 Power Supply</u>				
Clamp	Function		Description	
L1			L1 Phase	
L2	look		L2 Phase	
L3	Type plate		L3 Phase	
Ν			N Neutral	
PE	Power Supply		PE Ground	Power Supply
or:				
PE	Power Supply		PE Ground	
L1	look		L1 Phase	
Ν	Type plate		N Leiter	
PE	Power Supply		PE Ground	
4.5 Port for the fau	lt signal relay per invert	<u>er</u>		
Function	Description		– – – – – – – – – –	 • 1
Alarm relay	Alarm contact 1		2	2
changer	Alarm contact 2		— — 3	
230V 1 A limit	Alarm contact 3			
			Power On, no failure	Power Off or failure
4.6 Port for the ext	ernal inputs			
Function	_	Description		
external "Start"		Ext. 1	4	
external "Fix speed	" / "Reset"	Ext. 2	5	
external "low water"	د	Ext. 3	6 (only MARH)	external
external "set point 2		Ext. 4	7 (only MARH)	T (
PTC +			, (only in her)	l Input I
		Pump 1-x	08/18/28/38 (only MARH)	Input
PTC -		Pump 1-x Pump 1-x	08/18/28/38 (only MARH) 79/79/79/79 (only MARH)	Input
PTC -		Pump 1-x Pump 1-x	08/18/28/38 (only MARH) 79/79/79/79 (only MARH)	PTC
PTC - 4.7 Port for the ext	ernal outputs / relays	Pump 1-x Pump 1-x	08/18/28/38 (only MARH) 79/79/79/79 (only MARH)	PTC
PTC - <u>4.7 Port for the extr</u> Function	ernal outputs / relays	Pump 1-x Pump 1-x Description	08/18/28/38 (only MARH) 79/79/79/79 (only MARH)	PTC
PTC - <u>4.7 Port for the extr</u> Function External Out 1 activ	<u>ernal outputs / relays</u> e fan 230V/1A	Pump 1-x Pump 1-x Description Ext. 1	98/N	PTC
PTC - 4.7 Port for the exte Function External Out 1 activ Fixed function as an	ernal outputs / relays e fan 230V/1A active fan relay with pow	Pump 1-x Pump 1-x Description Ext. 1 yer> 5.4 kW	98/N	PTC
PTC - 4.7 Port for the exte Function External Out 1 activ Fixed function as an External Out as 2.3.	ernal outputs / relays e fan 230V/1A active fan relay with pow	Pump 1-x Pump 1-x Description Ext. 1 Yer> 5.4 kW	98/N	PTC
PTC - 4.7 Port for the exte Function External Out 1 activ Fixed function as an External Out as 2,3,4 parameterised PE 2	ernal outputs / relays e fan 230V/1A active fan relay with pow 4 P.F. parameterised 20V 1 A maximum	Pump 1-x Pump 1-x Description Ext. 1 Ver> 5.4 kW Ext. 2, Ext. 3.4	98/N 90/91 92/93/94/95 (only MARH)	PTC
PTC - 4.7 Port for the extr Function External Out 1 activ Fixed function as an External Out as 2,3,4 parameterised, P.F. 2 The external input of	ernal outputs / relays e fan 230V/1A active fan relay with pow 4 P.F. parameterised 230V 1 A maximum	Pump 1-x Pump 1-x Description Ext. 1 ver> 5.4 kW Ext. 2, Ext. 3,4 Farriced Eurotic	98/N 90/91 92/93/94/95 (only MARH) 92/93/94/95 (only MARH)	PTC external Output/
PTC - 4.7 Port for the extr Function External Out 1 activ Fixed function as an External Out as 2,3, parameterised, P.F. 2 The external input a	ernal outputs / relays e fan 230V/1A active fan relay with pow 4 P.F. parameterised 230V 1 A maximum nd outputs can be paramet	Pump 1-x Pump 1-x Description Ext. 1 ver> 5.4 kW Ext. 2, Ext. 3,4 terised. Function	98/N 90/91 92/93/94/95 (only MARH) 92/93/94/95 (only MARH) on, see "Messages" menu.	PTC external Output/ Relay

Caution!

Use shielded cable and connect it to the grounding clamps in the cabinet! The maximum length of the signal lines must not exceed 20 meters.

4.8 Port for the transducer Function	Description	P24 OI
1x Transducer signal OI 4-20mA	Transducer 86	
1x Reference voltage L VDC -	Transducer 87	Braun Schwarz
1x Transducer signal OI 4-20mA	Transducer 88 (only MARH)	
1x Reference voltage L VDC -	Transducer 89 (only MARH)	

Description

U V W

Caution!

Use shielded cable and connect it to the grounding clamps in the cabinet! Terminal assignment note (see transducer plate)!

4.9 Port for the motor / pump

Clamp	Function
U	3 phase motor
V	look
W	wiring diagram

Caution!

The motor must be connected according to the output voltage: star or triangle.

The nameplate on the motor note!

Check the correct connection of power, sensor, and control lines.

Check once again before switching on the mains voltage, all connections are correct!

When disturbances to the notes under 9.2 Troubleshooting note!

Motor

4.11 Port from GSM Modem

Connect the controller to the GSM modem (terminal) with the appropriate cable. Connect the antenna and power cord. Eat a good alignment of the antenna for proper cellular data connection. Set the power is always active together safely with the MAR-controller.



4.14 SIM card

You need a registered SIM card. Put the SIM card into the modem. Turn on the modem / plant one. If you activate the "GSM / User" menu GSM, they can set the phone book and the GSM - Modem use.





There are currently 3 users allowed as phonebook entry. User 3 has permission for the remote adjustment.. A remote adjustment of the set points is possible. A separate operating instructions for Card reader is supplied with the GSM modem. At any time you a SIM card from the manufacturer can be preset. If you have questions or special solutions, please contact to the manufacturer.



When setting the SIM card, ensure that you disable the PIN code! In case of wrong input of data, the SIM card is not detected correctly! The power supply from the GSM modem must always be active together with the EDR-1! Pay attention to proper cellular data connection!

Set only with the MAR menu the SIM card!

SMS commands: see 10.3 Complete SMS commands: see operating manual MAR ..- GSM2.

A smartphone app for Android from: 4.xx

stands for simple SMS service available.

Check with the manufacturer.





5. panel Description MAR

Control panel with two-line LCD display for parameters and operating data:





The arrow keys

Select the functions (scrolling) Enter / change data.

The **SET** / **RESET** - keys Storing input data, Error acknowledgment

The red LED lights when the disorder. The green LED lights when active control.

Output displays:

Active main screen for "external" / "internal" setpoint status





GSM is active: a mobile network connection. GSM is inactive: There are no cellular network connection. In addition, the alarm lamp will light and the display we "no network" message.

Modbus is active: Currently data can be queried. Modbus is inactive: No data is retrieved.



Analog set-point: The set-point values are given by the analog input.

Test mode is active: All monitoring functions are disabled!

5.1 panel Description MARH

Control panel with four -line LCD display for parameters and operating data:



The arrow keys

The SET / RESET - keys Storing input data, Error acknowledgment

Enter / change data.

The red LED lights when the disorder. The green LED lights when active control.

Select the functions (scrolling)

Output displays:

Active main screen for "external" / "internal" setpoint status

01,50 bar Auto P1 Auto P2 13:48:32 Auto P3 P1: 048Hz, 015,5A P2: 048Hz, 015,5A P3: 048Hz, 015,5A P4: 000Hz, 000,0A ₽	01,50 bar Auto P1 Auto P2 13:48:32 Auto P3 Auto P4 P1: 048Hz, 015,5A P2: 048Hz, 015,5A P3: 048Hz, 015,5A P4: 000Hz, 000,0A	01,50 bar Auto P1 Auto P2 13:48:32 Auto P3 Auto P4 P1: 048Hz, 015,5A P2: 048Hz, 015,5A P3: 048Hz, 015,5A P4: 000Hz, 000,0A
01,50 bar Auto P1 Auto P2 13:48:32 Auto P3 Auto P4 P1: 048Hz, 015,5A P2: 048Hz, 015,5A P3: 048Hz, 015,5A P4: 000Hz, 000,0A	01,50 bar Auto P1 Auto P2 13:48:32 Auto P3 Auto P4 P1: 048Hz, 015,5A P2: 048Hz, 015,5A P3: 048Hz, 015,5A P4: 000Hz, 000,0A	01,50 bar Auto P1 Auto P2 13:48:32 Auto P3 Auto P4 P1: 048Hz, 015,5A P2: 048Hz, 015,5A P3: 048Hz, 015,5A P4: 000Hz, 000,0A
O1,50 bar Auto P1 Auto P2 13:48:32 Auto P3 P1: 048Hz, 015,5A P2: 048Hz, 015,5A P3: 048Hz, 015,5A P4: 000Hz, 000,0A	01,50 bar Auto P1 Auto P2 13:48:32 Auto P3 Auto P4 P1: 048Hz, 015,5A P2: 048Hz, 015,5A P3: 048Hz, 015,5A P4: 000Hz, 000,0A	01,50 bar Auto P1 Auto P2 13:48:32 Auto P3 Auto P4 P1: 048Hz, 015,5A P2: 048Hz, 015,5A P3: 048Hz, 015,5A P4: 000Hz, 000,0A



GSM is active: a mobile network connection.

GSM is inactive: There are no cellular network connection.

In addition, the alarm lamp will light and the display we "no network" message.

Modbus is active: Currently data can be queried. Modbus is inactive: No data is retrieved.



Analog set-point: The set-point values are given by the analog input.

Test mode is active: All monitoring functions are disabled!

6. Programming instructions / operation / startup messages

<u>6.1 General operation of the displays</u>

If operated from the output side of the \checkmark arrow key so you can access the desired values Here the nominal values of the system are set. If the \checkmark arrow key is pressed again, we come to the operating parameters. Here, the operating parameters of the system are set.

If operated from the output side of the \blacktriangle arrow key so you can access the various operational indicators. Pressing the \blacktriangle arrow key the next operation screen appears.

The pump control is made by turning the switch Hand/0/Auto- in operation. If the system is via an external command, the external contact must also be started to be closed.



The pump control MA can optimally be adapted to all possible operating conditions by adjusting various functions and operating parameters in individual cases. The system is programmed at the time of delivery to keep the cost of commissioning as low as possible. To enter the necessary data, a menu item can be called at any operating parameters. The menu items can be called as described below. Each parameter has a setting in which selected either an option or a range of values can be set.

6.2 Requirements for the commissioning of the MA Controller

Before the control is put into operation, the following requirements must be met: Plant / pump suction and pressure side is connected to the pipe! Piping and pumps are vented! Electrical connection is made and checked!

6.3 First turn on the MA Controller

Caution!

When the safely start is chosen, it comes after turning on the power or after a power failure, automatic restart of the pump!

Switch on the power! After turning on the main switch / the mains voltage, the stored operating data in the drive controller (Modbus) are compared.

The following message appears on the display:

Molitor
Antriebstechnik GmbH
EDR2-MARH S-Nr.xxxxx
Version: 1.xx[x-xxx]

The MA-controller searches the GSM query image according to a GSM modem and tries to establish a connection.

The wait time is about 30 seconds.

GSM-INIT			
wait !			
Message if no mode	m is con	nected!	
GSM-INIT			
No modem connected !			
f there is no modem connected, changes the EDS 2 to this main:			
01,50 bar	Hand Aus	P1 P2	
13:48:32	Aus	P3	

P1: 000Hz, 000,0A

Aus

P4

The wait time is about 30 seconds.

Message when an error has occurred!

-- GSM-INIT --Error SIM / phone book !

If an error occurred during the modem, change the EDS-2 to this main:



6.4 Correct connection from the modem with / without network coverage

The MA-regulator starts up after the splash screen! with the GSM query image: It will attempt to connect to the GSM module. The wait time is about 30 seconds.

	GSM-INIT	
wait	: !	

Message when the modem is connected correctly! The modem sends the status.

GSM-INIT OK ! sample system phone number +49160xxxxxx		
GSM-INIT OK !	GSM-INIT OK !	GSM-INIT OK !
Mobil 1	Mobil 2	Mobil 3
phone number	phone number	phone number
+49150xxxxxxx	+49170xxxxxx	+49171xxxxxxx

If a modem connected to network coverage, changes of the MA-regulator for this main:

01.	50 bar	Hand I	21
40	40.00	Aus 1	22
13:	48:32	Hand I	23
		Auto I	24
P1:	048Hz,	017,0A 🖁	

If the modem is connected without network, changes of the MA-regulator for this main

01,	50 bar	no
13:	48:32	network!
P1:	048Hz,	

If the communication is set to Modbus this is indicated by the appropriate symbol. Active mode of input / output data Mode with inactive input / output data

01,50 bar	Auto P1 Auto P2
12.10.22	Auto P3
13.40.32	Auto P4
P1: 000Hz,	000,0A 🛱

	F F F
01,50 bar	Auto P1 Auto P2
13:48:32	Auto P3 Auto P4
P1: 000Hz,	000,0A F

If the communication is set to analog, this is indicated by the appropriate symbol. After the initialisation is complete, the power indicator will appear:

Active Power indicator while "Poti" set-point

01 50 hor	Auto Pl
01,50 Dal	Auto P2
12.12.22	Auto P3
13.40.32	Auto P4
P1: 000Hz,	000,0A 🖌

Active power indicator during active test run



Active Power indicator while "internal" set-point

01 50 bar	Auto	P1
01,30 Dai	Auto	Р2
12.12.22	Auto	РЗ
13.40.32	Auto	P4
P1: 000Hz,	000,0A	

Active Power indicator while active fire mode

01 50 hor	Auto Pl	
101,50 Dar	Auto P2	
12.10.22	Auto P3	
13.40.32	Auto P4	
P1: 000Hz,	000,0A 🛆	

7. Display / operational messages

7.1 Information displays

Pumps off

The MA controller is switched off. The message "Pump Off".

01,50 bar	Pump
13:48:32	UII
P1: 000Hz,	000,0A

01,50 bar	Pump Off
P1: 000Hz,	000,0A

External off

The MA controller is connected via an external input. If the connection is open, the message "External Off" appears. The respective pump (s) are stopped. The red LED lights. The alarm relay is not activated.

01,50 bar	Extern Off
13:48:32 P1: 000Hz,	000,0A



External low water

The MA controller is connected via an external input. If the connection is open, the message "low water" will appear. The respective pump (s) are stopped. The red LED lights. The alarm relay switches.

01 50 bar	low
12,10,20	water
13:40:32 P1: 000Hz,	000,0A

01,50 bar		low water
P1:	000Hz,	000,0A

Fill in active

If the "under-pressure" to be active, the MA-regulator is operated in fill mode until the pressure for the first time is balanced. The red LED lights. The alarm relay is not activated.



01,50 bar	Fill mode
P1: 035Hz,	002,0A

Safe Start is active

If the function "Safe Start" to be selected, the MAR controller is operated in fill mode. The master pump is active. The slave pump (s) is inactive. The red LED lights. The alarm relay is not activated.

01,50 bar	Safe Start
13.40.32 P1: 035Hz,	002,0A

01,50 bar	Safe Start
P1: 035Hz,	002,0A

Top pressure

The current pressure is above the set upper pressure. The MA controller controls off to prevent a further rise in pressure. It appears the message "top pressure". The red LED lights. The alarm relay is not activated..

01,50 bar	Тор
13.48.32	pressure
P1: 000Hz,	000,0A

01,50 bar		• Top pressure	
P1: 000	Hz, ()00,0A	

Stopped plant

The MA-controller is connected via an external emergency stop. It appears the message "Stopped plant". The pump (s) are stopped. The red LED lights. The alarm relay switches. "Restart" via GSM or reset - function.

01,50 bar Stopped plant	01,50 bar	Stopped plant
13:48:32 P1: 000Hz, 000,0A	P1: 000Hz, 00	00,0A

8. Operating Indicators / Main Menu / Setup

8.1 Select MARH operating indicators



With the \blacktriangle arrow key, the next screen is displayed.

Pressing the same arrow key the next screen is displayed.

Use the $\mathbf{\nabla}$ arrow key, the previous screen is displayed.



If the display is "hours of operation" is displayed and the \blacktriangle arrow key is pressed, so you get to the error memory. From the fault memory of the **SET / RESET** button must be pressed to return to the initial display.

MARH active messages

Operating Status: time, pressure, frequency, current P1/P2 ..., equipment temperature



8.2 Select MAR operating indicators



With the \blacktriangle arrow key, the next screen is displayed.

Pressing the same arrow key the next screen is displayed.

Use the $\mathbf{\nabla}$ arrow key, the previous screen is displayed.



If the display is "hours of operation" is displayed and the \blacktriangle arrow key is pressed, so you get to the error memory.

From the fault memory of the **SET / RESET** button must be pressed to return to the initial display.

Notice!

MAR active messages

Operating Status: time, pressure, frequency, current P1/P2 ..., equipment temperature



Option page GSM:

GSM modem:

You can use the "Communication" menu, activate a GSM modem

and set in the phonebook, the system and the user and provide input or output.

On this page you can change the Contract, see the signal strength (0-30), to interrogate their accounts and each user (Be.x) "A" or turn "off". When the credit card contract is always at \notin 99.99.

If the cursor is flashing, the value using the **arrow** \blacktriangle **button**, **arrow** \lor **button** and the **SET** / **RESET** button can be set. After confirming "OK", the change is adopted.

		RESET
contract:P S12	contract:P S12	contract:P S12

Option Page Counter:

Set Counter:

You can configure via the menu "Messages" inputs as counter

To put the meter on, press **SET** / **RESET button** for 5 seconds when displaying water meter. If the cursor is flashing, the value using the **arrow** \blacktriangle **button**, **arrow** \lor **button** and the **SET** / **RESET button** can be set. After confirming "OK", the change is adopted.

	A V RESET	RESET
water-counters: Z1 /10001 : 154sqm Z2 /100 1 : 100,0sqm Z3 /10 1 : 10,00sqm Z4 /1 1 : 10000 1	water-counters: Z1 / <u>10001</u> : 154sqm Z2 /100 1 : 100,0sqm Z3 /10 1 : 10,00sqm Z4 /1 1 : 10000 1	<pre>water-counters : Z1 /100 1 : 15,4sqm Z2 /100 1 : 100,0sqm Z3 /10 1 : 10,00sqm Z4 /1 1 : 10000 1 OK</pre>

Reset the counter:

To reset the counters to **00000**, the following procedure:

Go to the page "water meter" and hold the SET / RESET button for about 10sec. pressed!

Option MODbus page (only MARH):

MODbus set:

You can activate the MODbus slave via the "Communication" menu. For the data list, use the manual: "EDR MODbus". MODbus Address: 1,250, Parity: N. L. G. Baud Pate: 9600, 19200, 38400

MODbus Address: 1-250, Parity: N, U, G, Baud Rate: 9600, 19200, 38400.

To set the MODbus data rate, press **SET / RESET button** for 5 seconds when viewing Modbus. If the cursor is flashing, the value using the **arrow** \blacktriangle **button**, **arrow** \blacktriangledown **button** and the **SET / RESET button**

can be set. After confirming "OK", the change is adopted.



Option Page SD card (only MARH):

Remove SD card:

You can take notes information on the onset of an SD card.

To remove the SD card, press SET / RESET button for 5 seconds when displaying SD card. If the cursor is flashing, remove the SD card with the arrow \blacktriangle button, arrow \forall button and the SET / RESET button can be set. After confirming "OK", the change is adopted.



SD card set:

To set the data rate of the SD card, press **SET / RESET button** for 5 seconds at the display SD card and navigate with **arrow** \checkmark **button** to the second line. If the cursor is flashing, the value using the **arrow** \blacktriangle **button**, **arrow** \checkmark **button** and the **SET / RESET button**



SD card notifications: Data Rate:	1 Min	:1 min / 10 min / 1 hr / 10 sec
Specifications:	1/15, 0 (display examp 1 / = Current file 15 = Number of w , 0 = number of erroned	le) is written to the written data in the current file bus data
SD:	Err map (Display exam	pple)
Message:	SD: no	: no SD card inserted
Message:	SD: active	: data is written
Message:	SD: active + full	: data is overwritten
Message:	SD: Inactive	: data is not written
Message:	SD: Err Card Type	: SD Card is defective
Message:	SD: format	: no DS card inserted
File: 1.CSV	file name and file form	at for analysis in Numbers (MAC) or Excel (Microsoft)
Caution: W	hen setting the SD card in	nake sure the card is formatted. Empty SD card can not l



Caution: When setting the SD card, make sure the card is formatted. Empty SD card can not be read. The SD card must be described with matching empty files. If necessary, if you opt for empty files to the manufacturer.

8.2 Select the manual mode

Operational status MARH: Manual operation with FU, pressure, speed, current or with Fixed Pump

01,	50 ba	f Hand P1 Hand P2
10.	10.00	Hand P3
13.	48:32	Hand P4
P1:	035Hz,	015,0A
P2:	035Hz,	015,0A
P3:	000Hz,	000,0A
P4:	000Hz,	000,0A

01,50 bar 13:48:32	Hand Hand Hand Hand	P1 P2 P3 P4	
P1: active P2: active P3: inactive P4: inactive			H ^U A

Operational status MAR: Manual operation with FU, pressure, speed, current or with Fixed Pump

01,	50 ba	$^{\rm Hand}_{\rm Hand}$	P1 P2
P1:	035Hz,	015,0A	
P2:	035Hz,	015,0A	

-	
01,50 bar Hand P1 Hand P2	H ⁰ A
P1: active	(\land)
P2: inactive	$ \cup$

8.3 Time / Date

MARH Set time:

Press **SET / RESET button** for 5 seconds at the operating display time / date. If the cursor is flashing, the time and date using the

Arrow \blacktriangle button, arrow \lor button and the SET / RESET button can be set. After confirming "OK", the change is adopted.

			SET/ TESET				
14:59:17 15.01.13	Auto P1 Auto P2 Auto P3 Auto P4	<u>14</u> :59:17 15.01.13	Auto P1 Auto P2 Auto P3 Auto P4	<u>15</u> :59:17 15.01.13	Auto P1 Auto P2 Auto P3 Auto P4		
P1: 048Hz, P2: 000Hz, P3: 000Hz, P4: 000Hz,	015,0A 000,0A 000,0A 000,0A	P1: 048Hz, P2: 000Hz, P3: 000Hz, P4: 000Hz,	015,0A 000,0A 000,0A 000,0A	P1: 048Hz, P2: 000Hz, P3: 000Hz, P4: 000Hz,	015,0A 000,0A 000,0A 000,0A OK		

MAR Set time:

			SET/				
14:59:17	Auto P1	<u>14</u> :59:17	Auto P1	15:59:17	Auto P1		
15.01.13	Auto P2	15.01.13	Auto P2	15.01.13	Auto P2		
P1: 048Hz,	015,0A	P1: 048Hz,	015,0A	P1: 048Hz,	015,0A		
P2: 000Hz,	000,0A	P2: 000Hz,	000,0A	P2: 000Hz,	000,0A <mark>OK</mark>		



The menus are the same for all.

When storing the values is queried on demand,

if the values for pump 1, pump 2, pump 3 or 4 pump or pumps for all to be saved.

8.5.1 Adjust set-points

The set-points are set for the plant. The code (____), see page 17.



Notice!

The set-points menu is in limits "GW" inactive!

The set-points are inactive with external set-point!

Note: By pressing the seconds, the menu can be interrupted.

A V RESET		(A) (RESET
set-points	set-points Password Code:xxx	top press. : <u>05,00bar</u> target press: 04,00bar start press : 03,50bar diff.press : 00,10bar
	SET7 RESET	s-p.adjust : 1,00 overrun time: 5s
		l.delay time: 60s bridge time : 99Min

Explanation of parameters:

Enter the top pressure value at whitop pressure	ch the system will :05,00bar	be governed immediately. - 0,01bar - 99,99bar (1-4)		
Enter the target pressure value at w target pressure	which the system is :04,00bar	s to operate. - 0,01bar - 99,99bar (1-4)		
Enter the start pressure value at wh start pressure	iich the system wi :03,50bar	ll start again after the "Standby" - 0,01bar - 99,99bar (1-4)		
Enter the differential pressure at w differential pressure	hich the next pum :00,10bar	p will be switched on. - 0,01bar - 99,99bar		
Enter the set-point adjustment, in v Small 1 = target pressure drop; Lar set point adjustment	which the target preserved in target p	essure should be adjusted to the pipe. ssure increase. - 0,2 - 2,0 / 1,0=Aus		
Enter the delay time until the pump overrun time	to stop. :5s	- 0s - 999s		
If the limit function is active, the M by the zero flow cut-off, reboot wi With this function, they prevent the Monitoring for broken pipe or wate	A must - regulate th the external cor e irrigation a "run er shortage is activ	or after every shutdown to "Standby" nmand. dead" of the pump after the end of irrigation. ye after the bridge time.		
Enter the limit delay time until the limit delay time	plant is to go to " :60s	standby". - 9s - 199s		
Enter the bridging time until the pr bridging time	ressure monitoring : 1	g is active. - 1Min - 99Min		
Set-points for pressure switch operation (Fix pump operation):				
Enter the Stop pressure value at wh stop pressure	nich the system wi :04,00bar	i llstop - 0,01bar - 99,99bar (1-4)		
Enter the start pressure value at wh start pressure	nich the system wi :03,50bar	ll start again after the "Standby" - 0,01bar - 99,99bar (1-4)		

8.5.2 limit setting

The limits are set for the plant. The code (), see page xx.



The Limits menu is only in limits "GW" active!



These limits are inactive with external setpoint!

Notice

Note: By pressing the entropy - button for 5 seconds, the menu can be interrupted.

	(A) (V) (BETT) RESET	A RESET
Limits	Limits Password Code:xxx	TO - press. : <u>09,00bar</u> TT - press. :+00,50bar LO - press. : 04,00bar LT - press. :-00,50bar Diff.press. : 00,10bar s-p.adjust : 1,00 overrun time: 5s
		l.delay time: 60s bridge time : 99Min

Explanation of parameters:

Enter the low OFF pressure at which the system will turn off. low off pressure :04,00bar - 0,01bar - 99,99bar (1-4) Enter the low test pressure at which the system will turn off when the pressure drops. :00,50bar - 0,01bar - 09,99bar (1-4) low test pressure (-) Enter the top OFF pressure at which the system will turn off. :09,00bar top off pressure - 0,01bar - 99,99bar (1-4) Enter the top test pressure at which the system will turn off when the pressure rises. :00,50bar -0,01bar -09,99bar (1-4)top test pressure (+) Enter the differential pressure at which the next pump will be switched on. differential pressure :00,10bar - 0,01bar - 99,99bar Enter the set-point adjustment, in which the target pressure should be adjusted to the pipe. Small 1 = target pressure drop; Larger 1 = target pressure increase. set point adjustment - 0,2 - 2,0 / 1,0=Aus :1,0 If the Limits menu is active, the MA must - regulator after every shutdown by the "limits" to reboot with the external command. With this function, they prevent the irrigation a "fizzle" of the pump after the end of irrigation. Monitoring for broken pipe or gas shortage is active after the bridging time. The pressure limit for the water shortage are 50% of the upper limit pressure. Enter the delay time until the pump to stop. overrun time - 0s - 999s :5s Enter the limit delay time until the plant is to go to "standby". limit delay time :60s - 9s - 199s Enter the bridging time until the pressure monitoring is active. bridging time - 1Min - 99Min :1

8.5.3 MAR adjust times

times	times Password Code:xxx	reduction : 000% r-time On : 20:00h r-time Off : 23:00h
		test time : 10:00h duration : 99s T.Intervall : 0 days
		timer : A/E/T On time : 00:00h Off time : 00:00h expir. time : 180Min

Explanation of parameters:

Enter the percentage of the set pressure for the pressure drop, at which the system is to operate. This feature gives you the ability to reduce the energy consumption of the pump. **pressure reduction** : 0 - 0 - 100 % / 0 = off

Reduction	time	on	:xx:xx	h	-	00:00	-	23:59	h
Reduction	time	off	:xx:xx	h	-	00:00	-	23:59	h

Select the test run for the pump. This feature gives you the ability to run the pump once every 24 hours with manual frequency. This function can prevent seizing of the pump.

test time	:10:00h	- 00:00 - 23:59 h
duration	:20s	- 0 - 999s with manual frequency
T.Intervall	:0 days	-0 - 30 days (0 days = Off)

Enter the mode for the timer, at which the system is to operate. **Timer - A/E/T** : 0 - 0 - 100 % / 0=off

A	=	off	System or	perates	without t	imer			
Е	=	on	System op	perates	with time	r			
т	=	on exp.	System op	perates	with expi	ration	time	(egg	timer)

Enter the values for the timer. This feature gives you the ability to control the pump by time. The timer is active every day.

On	time	:xx:xx	h	-	00	-	23	h
Off	time	:xx:xx	h	-	00	-	23	h

Enter the values for the countdown timer (egg timer). This feature gives you the ability to control the pump by time. The countdown timer is always active with the start command.

Enter the values for the expiry timer (egg timer). This feature gives you the ability to control the pump after time. The countdown timer is always active with the start command. **With an additional button "Timer Set", which is activated via a digital input "TIS", the set time let's count up.** Example: base time T = 10min. Briefly press the key: new time: 20min; Button press: new time now 30min. A longer press and hold the button, the timer value is reset to the base setting eg 10min. reset. The set time is active only once. Thereafter, the base is always active time. The time base can be set "times" in the menu.

expiration time :10 Min - 001 - 999 Min

8.6 Base Setting

Base Setting	Base Setting	number INV	:	4
	Password	<u>n</u> umber FIX	:	0
	Code:xxx	INV 1	:	AW
		INV 2	:	AW
		INV 3	:	AW
	RESET	INV 4	:	AW
		FIX 1	:	AW
		FIX 2	:	AW
		FIX 3	:	AW
		FIX 4	:	AW
		setpoints	:	1
		expvessel	:	Y
		operating mode	:	A

Explanation of parameters:

Enter the number of the frequency converter (FU) and the number of direct (contactor / soft starter) (FIX) pumps. In the parameter in the parameter FIX FU and they determine the function of the pump. When multi-operation every **300 minutes (adjustable) are changed**, the pump between master and slave.

```
Enter the Number of frequency inverter (IV) pumps.
Number INV
                                     - 1 - 2 (4)
                      :4
Enter the number of direct (contactor / soft starter) (FIX) pumps.
Number FIX
                                     - 0 - 2
                       :0
Enter the function of each frequency inverter pump.
INV x
                       :AW
                                     - AW - PW - AF - PF
Enter the function of the respective direct (contactor / soft starter) pump.
FIX x
                                     - AW - PW - AF - PF
                       :AW
Meaning of abbreviations:
A 1-4 =
              Active Pump in System
                                                     (always active as needed)
 P \ 1-4 =
               Passive Pump in System
                                                     (active only on fault of another pump)
W 1-4 =
               Changing the pump in System
                                                     (after running, hours of operation., fault)
               Fix position in System
 F 1-2 =
                                                     (always at the same position)
 B 0-1 =
               Booster Pump in System
                                                     (last pump in the system switches on)
 J 0-1 =
               Jockey Pump in System
                                                     (first pump in the system turns off)
Enter the number of the set-points, at which the system is to operate.
                                            - 2-MAR-Input 1.1 - S1
Number of set-points
                             :1/2
Select whether the system works with or without expansion vessel.
Expansion vessel.
                              :Y
                                             - no / yes
Turn the limit function by the irrigation systems as required.
If the limit function is active, the system turns off and has to be restarted with the external command.
Select the operating mode of the system.
```

opera	ting	mode : DR	- (DR) pressure control
DR	=	pressure	A transducer is active for pressure regulator
DF	=	Pressure + firefighting	special function
DG	=	Pressure + limit	with restart inhibit is active
GW	=	Limit control	with restart inhibit is active
ME	=	Volume	A MID is for volume control
DU	=	flow	A transducer is active for flow control
TH	=	heating	A transducer is active for temperature control
TK	=	cooling	A transducer is active for temperature control
NF	=	level filling	A transducer is active for level control
NL	=	level empty	A transducer is active for level control

8.7 Set electric pump / electric motor

Pump/Motor FU	Pump/Motor 1/2/3/4 Password Code:xxx	<pre>read INV : rotating : accelerate : decelerate : rated curr.: rated volt : rated freq.: min freq. : max freq. : hand freq. : fix freq. : motor char.: carr. freq.: vario freq.: motor prot.: ph.er.outp.:</pre>	P1 R 01,0s 02,0s 015,0A 400V 050Hz 020Hz 050Hz 035Hz 050Hz K 05,0kHz A A
------------------	--	---	--



Select whether you want to read the data from read INV	om the respective freq : P1	uency inverter. – P1 / P2 / P3 / P4
Enter the rotation direction of the pump (s). rotating direction	AC phase angle does :R / L	s not matter! - Right / Left
Enter the Acceleration time of the pump (s). acceleration time	Recommendation: 1- :03,0s	-3 seconds. - 0,01s - 99,9s / only manual operation
Enter the deceleration time of the pump (s). deceleration time $\$	Recommendation: 2- :05,0s	-10 seconds. - 0,01s - 99,9s / only manual operation
Enter the motor rated current of the pump (srated current	s). Data: See namepla: :xxx, 0A	te. - 0,01A - 199,9A
Enter the motor voltage to the pump (s). The rated voltage $\$	e setting they found o : 400∨	- 200V - 480V
Enter the rated frequency of the pump (s). If With this function, the nominal frequency or rated frequency	Data: See nameplate. f the pump is set. : 50Hz	- 1Hz - 200Hz
Enter the minimum frequency of the pump of entered. This way of setting the pump power min frequency	(s). This feature gives r can be limited. : 25Hz	s you the option of the minimum frequency of the pump for operation - 1Hz - 200Hz
Enter the maximum frequency of the pump. This way of setting the pump power can be max frequency	This feature gives yo limited. : 50Hz	ou the option to enter the maximum frequency of the pump for operation.
Enter the hand frequency in Hz, a hand, in v hand frequency	which the respective e : 35Hz	engine in manual mode is to move up and down - 1Hz - 200Hz
Enter the fixed frequency for the respective current operation to change. If a SMS - start fix frequency	pump with the limit s t command sent without 50Hz	switch is to operate. This rate can be expressed by SMS - command (option) for the but a value, the system works with the fixed frequency. - 1Hz - 200Hz
Select the motor characteristic (Constant / q Recommendation: Square for centrifugal pu motor characteristic	uadratic / specific) of imps; constant for sub : K	f the pump. With this function, the power consumption of the pump can be changed. bmersible pumps; specifically at frequency inverter problems. - Constant / quadratic / specific
Enter the carrier frequency of the pump (s). to use with different cable lengths between p carrier frequency	Low carrier frequenc pump and drive. : 5000Hz	z - 2000Hz - 9999Hz
Select the Vario - carrier frequency of the pr to improve.	ressure control. The V	Vario - carrier frequency cause changes in engine noise to the soundscape for people
vario - carrier frequency	:A	- off / on
Select the motor protection function. motor protection	:A / K	- off / PTC / (PT100)
Select the phase failure detection output of phase error output	the pressure control. 7	The phase loss detection protects the motor cable against interruption. - Aus / Ein

8.8 Adjustment of transducer

Transducer	Transducer Password Code:xxx	Sensor 1 : ED Sensor 2 : RD Sensor 1 bar/m/C : 10,0 Sensor 2 bar/m/C : 10,0 Sensor 0ffset m/C: 0 Sensor deviation : 010% Aus bar /m /C : 0,50 Ein bar /m /C : 1,00 Ramp On bar/m : 1,50 Bamp Frequency : 050Hz
		Ramp On bar/m : 1,50 Ramp Frequency : 050Hz
		Ramp off bar/m : 2,00 Sensor mA/V : mA

explanation of parameters:

Enter the	transducer type one for press	ure control.	
sensor	1 :A	- A - ED -	VD - VN - RD - RN - ET - TW - MD* - S
Enter the	transducer type one for press	ure control.	
sensor	2 (only MARH) : A	- A - ED -	VD - VN - RD - RN - ET - TW - MD* - S
A =	off	transducer	has no function Attention!System will not function!
E =	on	transducer	acting as a master sensor
D =	pressure	transducer	works with 4-20mA and bar scale
N =	level	transducer	works with 4-20mA and cm scale
M =	mass sensor	transducer	operates with a flow (sqm / h)
т =	temperature	transducer	operates with temperature (C $^{\circ}$)
s =	remote setpoint	transducer	works with 4-20mA for a Remote set-point (%)
DD =	Difference	transducer	2-1 operates with the differential (only MARH)
VD =	inlet pressure	transducer	2 operates as a pressure monitoring (only MARH)
VN =	inlet level	transducer	2 operates as a level monitoring (only MARH)
RD =	redundant	transducer	operates on comparison press. (Redundant) (only MARH)
RN =	redundant	transducer	operates on comparison level (Redundant) (only MARH)
TW =	temperature	transducer	2 operates as temperature monitors (only MARH)

Enter the operating range for the transducer. Data: See type plate sensor. sensor value 1 bar /m :10,0 - 0,00 - 99,99

Enter the operating range for the transducer. Data: See type plate sensor. **sensor value 2 bar /m** :10,0 - 0,00 - 99,99

Enter the offset value for the display. At level is the ground level, at temperature of negative temperature value, enter. This feature gives them the opportunity to display the actual water level and the actual temperature. Sensor Offset :0 - 0 - 100 (°C / m) (only sensor 2!) (only MARH)

If necessary, select the dry run protection, in which the system will shut down when running dry. If the pressure / level below or operated the digital input is switched off due to a "dry run". If "Always" is selected, the dry run is also active in manual mode. No automatic restart after the dry run!

Enter the transducer deviation in% for redundant operation, or when the plant is shut down to "Sensor error". This feature gives them the opportunity to compare two sensors. **sensor deviation** :10% - 0% - 100%

Enter the switch-off of the form / level monitoring, with which the system will turn off. off switch bar /m : 1,00 - 0,00 - 99,99

Enter the switch-on of the form / level monitoring, with which the system will turn on. on switch bar /m :1,50 - 0,00 - 99,99

Enter the ramp value of the form / level monitoring, with which the system will operate at a lower frequency. ramp on bar /m :1,80 - 0,00 - 99,99

Enter the frequency of the ramp form / level monitoring, with which the system will operate. **ramp frequency** :50Hz - 030Hz - 200Hz

Enter the frequency of the ramp form / level monitoring, with which the system will operate. ramp off bar /m :1,0 - 0,00 - 99,99

Select the signal input for the transducer. Data: See type plate sensor. This feature lets you choose the option signal between 0-10V and 4-20mA. (See special connection diagram) sensor input :mA - mA / V / mA=MAR / V=FU MOD-Address 101

8.9 adjust controller

Controller	Controller	PID P gain	:	<u>0,50</u> 0,50s
	Code:xxx	test phase	:	050%
	SET/ RESET	speed Factor	:	050% 025Hz
		SW-off delay	:	02s
		switchover T. changeover T.	• • : • :	5s 300Min

Explanation of parameters:

Enter the PID P gain of pressure control. Ensures the rapid adjustment of the pump to the desired value. - 0,01 - 9,99 PID P gain :0,50 Enter the integration time of the PID controller. Ensures the rapid adjustment of the pump to the desired value. - 0,1s - 9,99s PID-I time .0,50s Enter the Testing phase for the null sets a shutdown. Recommendation: 20%. See also "zero flow cutoff" testing phase :20% - 1% - 99% = 0,1- 0,99bar absolute Enter the load factor for the null sets shutdown. Recommendation: 50%. See also "zero flow cutoff" load factor :50 - 1% - 99% from Inverter Enter the speed factor for the null sets shutdown. Recommendation: 50%. See also "zero flow cutoff" speed factor - 1% - 99% from Inverter :50 Enter the cutoff frequency for the zero quantities shutdown. - 1Hz - 200Hz switch-off frequency :35Hz Enter the time delay for the zero quantities shutdown. switch-off delay - 1s - 99s :5s Enter the time delay for the zero quantities shutdown. switch-on delay :8s - 1s - 99s Enter the changeover time for the gentle pump change a switchover time :5s - 1s - 19s Enter the operating time until the pump change. pump changeover time - 1Min - 999Min :300Min

8.10 Setting the safety

safety	safety Password Code:xxx	limit press. limit delay auto reset save start Save freg.	: <u>9,50bar</u> : 30s : A : 00Min : 035Hz
	EFT RESET	dry run low water under press. under press. lack delay pump guard guard freq. guard time leak. ctrl. runt. ctrl.	: I : I : K : 050% : 180s : A : 030Hz : 30s : 00 : 000Min

Explanation of parameters:

Enter the limit pressure value for The limit pressure monitoring is	r the MA-regulator and always active.	d the delay time at which the plant is off.
limit pressure limit delay	:99,99bar :30s	- 0,01bar - 99,99bar - 1s - 99s
Select the reset function for the l This feature gives you the option Note: The system restarts auto	MA-regulator. at fault automatically matically!	y to let 3 times in 20 minutes , start up again.
Auto Reset	:A	- AUS(OII) / EIN(ON) / 3X IN 20 MIN
If necessary, select the security s slowly and gently to fill. The Sa This function should be set by an Safe Start Safe frequency	tart for the MA-regula fe Start mode, only one n expert, or after consu :0 :35	 tor. If the Safe Start is selected, the pipe is after turning on the power or after a power failure, e pump operates at fixed speed for the time set. The next pump (s) is (are) stopped. ultation with the manufacturer. 0 - 99 Min 0 Min = off 0 - 200Hz
If necessary, select the dry run p If the pressure / level below or th If "Always" is selected, the dry r dry run : I	rotection, in which the ne corresponding digita un is also active in ma – Aus /	e system will shut down when running dry. al input is operated, shut down due to "dry run". unual mode. No automatic restart after dry run! Ein / always
If necessary, select the low wate If the pressure / level below or the also active in manual mode. Aut low water	r protection, in which the corresponding digits omatic restart after wa : I	the system will shut down if the water shortage. al input is operated, shut down due to "low water". If "Always" is selected, the water shortage is ter shortage. - Aus / Ein / always
Enter the% value of the pressure value. Example: 50% of 4.0 bar. pressure monitoring is disabled. In addition, the electronic protect If the pressure of at least 0.5 bar The dry run is also active in mar Under-pressure	monitoring, in which The under-pressure is tion against dry runnir is not reached after 30 ual mode. No automat : E	<pre>the system will shut down if the pressure deficiency. The% value refers to the set pressure from <2.0 bar active and switches to 3 minutes delay the pump. If "0%" is set, the under- ng, in which the system will shut down if the dry run, are elected to do so.) seconds, it will shut down due to "dry run". tic restart after a under-pressure / dry run. - Aus (off) / Ein (On) / always / Complete</pre>
Under-pressure lack delay	:50% :180s	- 0% - 100% 0% = off - 1s - 999s delay
A = off E = on I = always K = Complete	Under-pressure Under-pressure Under-pressure Under-pressure Electronic dry	has no function is active in automatic is active in automatic and manual is in automatic and manual active plus run (<0.5 bar in 30s)
The submersible pump guard en U-pump guard with a submersible submersible pump guard Guard frequency Guard time	sures the safe shutdow le pump operation. 1 :A :25Hz :99s	n of the pump at low speed. The function is important to protect submersible motors. Turn the - Aus (off) / Ein (On) - 25Hz - 200Hz - 9s - 99s
The leakage control ensures the submersible pumps from overhe leakage control	safe shutdown of the p ating. The switching fi :0	nump at to higher switching frequency. The function is important for example, To protect requency refers to one hour. - 0-99 per hour

Ensures the safe shutdown of the pump if running too long time. The function is important for example, To protect the pump against leakage. Select the type of the runtime control. Runtime control :0 - 0-999 Min / 0=Aus

8.11 MAR adjust messages

messages	messages	MAR-I.1.1	:	XXX
	Password	MAR-1.1.2 MAR-1.2.1	•	EAS
SET/ RESET	Code:xxx	MAR-I.2.2	:	WMO
$\bigcirc \bigcirc \bigcirc \bigcirc$		MAR-I.3.1	:	MSS
		MAR-I.3.2	:	MSS
		MAR-I.4.1	:	EAS
		MAR-I.4.2	:	WMO
		MAR-0.1.1	:	FUS
		MAR-0.1.2	:	VRS
		MAR-0.2.1	:	FUS
		MAR-0.2.2	:	TRO
		MAR-0.3.1	:	FUS
		MAR-0.3.2	:	WMS
		MAR-0.4.1	:	FUS
		MAR-0.4.2	:	HSS
		Relais-FU1	:	ALO
		•••		

Explanation of parameters:

EDR2 inputs and outputs (Picture above: example)

Digital inputs:

The digital inputs MAR-I 1.1 - 2.2 MARH-I 1.1 - 4.2 are adjustable. external inputs 1.1-4.2 :xxx - no function :MSS /MSO - motor protection (closer/opener) external inputs 1.1-4.2 external inputs 1.1-4.2 :SO1 - set-point 1 (closer) - set-point 2 (closer) external inputs 1.1-4.2 :SO2 :WMS /WMO - low water (closer/opener) external inputs 1.1-4.2 :TRS /TRO - drv run (closer/opener) external inputs 1.1-4.2 external inputs 1.1-4.2 :EAE /EAO - extern on /off (Closer/opener) external inputs 1.1-4.2 :NAO - Not-stop (opener) :RSS /RSO - Reset multiple possible (closer/opener) external inputs 1.1-4.2 :STS /STO - extern Trip (closer/opener) external inputs 1.1-4.2 :EHS /EHO - Extern Hand (closer/opener) external inputs 1.1-4.2 external inputs 1.1-4.2 :TIS - set timer (closer) external inputs 1.1-4.2 :SRS - start/stop/reset (only limit function) - Start/Stop (closer) switch Funktion external inputs 1.1-4.2 :SDS - Start/Stop (closer) pulse Funktion external inputs 1.1-4.2 :SPS external inputs 1.1-4.2 :SIS /SIO - Failed main fuse (Closer/opener) :HRS /HRO - Hunter relay only automatic (Closer/opener) :GFS /GFO - Limit Switches Fire Clear (Closer/opener) external inputs 1.1-4.2 external inputs 1.1-4.2 external inputs 1.1-4.2 :EP1-4(2) - extern on / off pump 1-4(2) (closer) :ZW1 - counter Eingang (closer) external inputs 1.1-4.2 - counter Eingang (closer) external inputs 1.1-4.2 :ZW2 external inputs 1.1-4.2 :EAP - On/Off Pump (Fermanox) (closer) **Digital outputs:** The digital outputs MAR-O 1.1 - 4.2 MAR-O 1.1 - 4.2 are adjustable. external outputs 1.1-4.2 :ALO /ALS - alarm (closer/opener) external outputs 1.1-4.2 :WMS - low water (closer) external outputs 1.1-4.2 :TRO external outputs 1.1-4.2 :DMS - dry run (opener) - low pressure (closer) external outputs 1.1-4.2 :NAS - Refill function (closer) external outputs 1.1-4.2 :SES - transducer error (closer) external outputs 1.1-4.2 :AFO /AFO - Fire alarm (closer/opener) no auto reset external outputs 1.1-4.2 :PAO /PAS - Pumps off (closer/opener) external outputs 1.1-4.2 :LAS - Run signal (Pump 1/2) (closer) - operating signal (closer) external outputs 1.1-4.2 :BES external outputs 1.1-4.2 :FUS - Ext.On/off FU1/2/3/4 (closer) - heating (cabinet) (closer) external outputs 1.1-4.2 :HZS external outputs 1.1-4.2 - cooling fan (cabinet) (closer) :VRS

Alarm relay:

The alarm relay FU 1 to FUx are preset as an opener and turn on power to "On". alarm relay FU1-FUx : ALO / ALS - alarm (can be changed closer/opener)

8.12 adjust communication

communication	communication	setpoint	:	Ī
	Code:xxx	SD card	:	A
	(A) (RESET	GSM / user	:	A
		ModBus	:	А

Explanation of parameters:

Select the input for the set-point of the pressure control. This feature gives them the ability to set pressure "I" on the keyboard or "A" on a 4-20mA signal or "M" via Modbus or "G" over GSM - pretend modem or select valid combinations. setpoint :I - I-Intern / A-Analog / M -ModBus / G-GSM :IG - IG-Intern+GSM / AG-Analog+GSM / MG-ModBus+GSM

Select the SD card to function. Settings are made on the SD side. This feature gives them the opportunity to collect data. SD card :A - Aus (Off) / Ein (On)

Select the GSM - to function. This function returns them to use the GSM function the way. SMS commands, refer to 10.3. GSM / user :A – (A) on / (E) off

For a new phone card, enter the PIN.

```
plant name
             :
irrigation
plant number :
+49155xxxxxxxx
        1 : on
user
+49150xxxxxxxx
       2 : off
user
+49160xxxxxxxx
        3 : off
user
+49170xxxxxxxx
         4 : off
user
+49177xxxxxxxx
  _____
credit
              :
*100#
card Contract :
Prepaid
```

Set the phone book on the SIM - card: Enter the plants - the names and the facilities - telephone number by one overwrite. With this name, the system reports via SMS. plant name :irrigation (z.B.) : +49155123456789 (z.B.) plant number Switch the user x "On" or "Off" and enter the phone number of the user. If this user is "on" he is entitled to operate the system. user x : Aus / Ein :+49150123456789 (z.B.) Change it if necessary free balance inquiry - phone number. :*100# (Germany) credit: Select the SIM - card Contract. With this, the SIM card - a management. SIM - card : Prepaid / contract

8.12.3 Setting the Phone Book

To set the system name or phone number, press **SET / RESET button** on the ad.Use the **arrow key** \blacktriangle **button**, **arrow key** \checkmark **button** and the **SET / RESET button** to change the letters or numbers. After confirming "OK", the change is accepted and the cursor jumps to the next field. To complete the name or phone number you provide a "!" And press "OK".

Now they can use the **arrow key** \vee **button** to the next user or go to the end.. All values are only active when they are stored in the "Communication" menu.

Select these characters a	nd numbers in circle	es: ABYZaby	vz0123456789+*# ABYZ</th <th>·</th>	·
Special function:	= delete	Special function:	! = finish	

Enter phone number Example:

Station +49 <mark>1</mark>	number:	Number 1 is selected and confirmed with "OK".
Station +491 <mark>5</mark>	number:	Number 5 is selected and confirmed with "OK".
Station +4915 <mark><</mark>	number:	Delete "<" is selected and the number "5" is deleted.
Station +491 <mark>6</mark>	number:	Number 6 is selected and confirmed with "OK".
•••		
Station +4916212	number: 234578 <mark>!</mark>	End "!" Selected to complete the entry and confirm with "OK".
Station +4916212	number: 234578	Entry ended.

Name and other users can be set as well.

Example User Off - On - Switch:

user	Х	:	off	"OK"
user	Х	:	off	"OK"
user	Х	:	on	" ▲ " or " ▼ "
user	Х	:	on	"OK"

Select the Modbus slave - to function. Settings are made on the MODbus page This function returns them to use the ModBus function the way. Register see 10.2. ModBus : A - Aus / Ein

8.13 adjust Internal

Intern	Intern Password	overheating Temp. warning	:	55C 30C
	Code·xxx	Ventilator On	:	35C
RESET		Ventilator Off	:	30C
		Frost warning	:	0C
		Heating On	:	5C
		Heating Off	:	10C
				_
		frame	:	A
		Dy.Threshold	:	000%
		Count. delay	:	5s
		SD-Version	:	0
		MB-Debug-S	:	0

Explanation of parameters:

If the values for the control cabine overheating On Temperature warning On	t temperature moi : 55C : 30C	nitoring. This function protects the cabinet from overheating. - 55°C - 70°C - 20°C - 30°C
The cabinet fan is at the set temper Ventilator On Ventilator Off	rature and off. Thi :35C :30C	is function depends on prior to the frequency line. - 25°C - 35°C - 20°C - 30°C
If the values for the control cabine Frost warning On	t frost monitoring :0C	. This function protects the cabinet against frost or condensation. - 0°C - 8°C (9°C = Off)
The cabinet heater is at the set tem Heating On Heating Off	perature and off. : 5C :10C	This function depends on prior to installation. - 1°C - 15°C - 6°C - 20°C
To the frame on the display appear frame	s around the displ A	lay foil stick better (active until power "Off"). - E / A
The dynamic threshold is active w Dynamic Threshold	hen the pressure s : ০%	witch operation. Special mode without conservator.
Enter the delay time for the counter. Counter delay	:5s	- 1s - 99s
Enter the polarity of the DS board. SD-Version	:0	- 0 / S

The MB-debug-S status indicates internal error. There is no setting.
MB-Debug-S :0 - internal use only

END Menu

9. Trip history monitor

9.1 Error indications on the display

In case of failure, the controller switches off and the pump (s) running freely.

Error messages can be acknowledged by prolonged pressing the error - button.

Error communication to external devices

The MA controller is connected via a serial link with an external device via the Modbus or the GSM modem. If the connection is interrupted or disturbed the pump (s) are not stopped.

The corresponding plain text error message appears on the display. The red LED lights. The alarm relay switches. Display examples:

Error	Error	no
Modbus	Modem	Network
••••	••••	••••

Error Connection

The MA controller is connected via a serial connection with the drive.

If the connection is interrupted or the relevant frequency is disturbed stopped.

The error message "Er51" appears in the display. The red LED lights. The alarm relay switches.

Display examples:

Hand P1	Er51 P1	Er51 P1
Er51 P2	Hand P2	Er51 P2
••••		••••

Error Transducer

The MA controller is connected via a cable to the sensor. If the connection is interrupted, the error message "sensor open". If the connection is disrupted, the error message "Sensor defective".

The respective pump (s) are stopped. The red LED lights. The alarm relay switches.

Display examples:

open	Error
Sensor	Sensor

Error printing, switching game, borehole pump, dry run, lack of water, motor protection

These error messages are software-related shutdowns. The respective error code is displayed, alternating with the plain text message in the display. The respective pump (s) are stopped. The red LED lights. The alarm relay switches. Display examples:

 Dry- Run	 low Water	 PTC P1 PTC P2
 Temp alarm	 Sensor deviate	 over- heating
 extern Alarm	 MS P1 MS P2	 low pressure

9.2 Error Messages Inverter MA-FU

The error "Er01" to "Er99" are error messages. The red LED lights. The alarm relay switches. Display examples:

Error messages by pressing the error by short external control of the Terminal "manual mode / Reset" reset.

Auto Pl	Er51 P1	Er51 P1
Er51 P2	Hand P2	Er51 P2
••••	••••	••••

Inverter MA-FU

error	Er04 : Motor overload (O.C.)
	Motor protection tripping. Reduce pump performance. Set motor protection!
error	Er05 : Over-voltage in the DC link with frequency (O.E.)
	Generator operation, power surge, check check valves. Call service!
error	Er06 : Phase error power input (P.F1)
	Phase failure. Check the fuses. Check mains voltage.
error	Er07 : Overload inverters (O.L1)
	Check inverter power: reduce pump performance. Set the parameters!
error	Er08 : under-voltage (L.U.)
	Grid voltage fault Check fuses, check mains voltage
error	Er09 : Inverter over temperature (O.H.)
	Inverter is too hot Reduce carrier frequency Cooling defective??
error	Er10 : Overload inverters (0.L2)
	Check inverter power: reduce pump performance. Set the parameters!
error	Erl1 : Under load frequency (Err) ?
	Motor load too low during operation. Increase engine power! Pumps deliver too little?
error	Er13 : External fault ESP
	Enter Wrong password on the frequency
error	Er14 : incorrect password frequency (ERR1)
CIICI	Frequency defective EU exchange Call service!
error	Er15 Errors motor parameters ERP2
CIIOI	Inverter set at the factory setting! Call service!
error	Er16 • Over current at standstill ERR3
CIICI	Motor load at a standstill too high Pump is blocked! Call service!
orror	Fr17 • Fault current measurement FPR
CIIOI	Fragmency defective EU exchange Call service
orror	Fr18 Motor guardad (OC1)
error	Motor protection tripping. Peduce pump performance. Set motor protection!
orror	Fr10 . Phase or rear (DEC)
error	Motor phase interrupted Check motor cable check motor
error	Er20 · Broken wire analog signal (AFrr)
CIIOI	Inverter set at the factory setting! Call service!
error	Er21 · Under Load frequency (EP3)
CIICI	Motor load too low during operation. Increase ensine power! Pumps deliver too little?
error	Fr22 • Inder Load frequency (EP)
CIIOI	Motor load too low during operation Interfacency (III)
orror	Fr23 • Index load frequency (FP2)
error	Motor lead too low during operation. Insequence on power During deliver too little?
	Er24
error	Lizer at the factory setting Call service
orror	Er25 . Theorem and the factory setting: Can service:
error	Lizz : Inverter parameter incorrect (ERRS)
	Inverter set at the factory setting! Call service!
error	Ers/ : Error PTC tripping (U.HI)
	I ne PIC thermistor has tripped. Reduce engine power. Improve cooling.
error	Er4/ : Communication error with the frequency inverter (CE)
	ModBus address wrong; ModBus connection faulty. Check connection or address?

Error MAR/MARH Controller

```
error Er51
                         : Communication error with the frequency inverter
        ModBus address wrong; ModBus connection faulty. Check connection or address?
                         : Transducer 1 open
error Er52
        The transducer connection is open. Check cable connection!
                        : Error Transducer 1
error Er53
        The transducer value is out of tolerance. . The transducer is defective?
                         : Transducer 2 open
error Er54
        The transducer connection is open. Check cable connection!
                         : Error Transducer 2
error Er55
        The transducer value is out of tolerance. . The transducer is defective?
error Er56
                        : Error sensor difference
        The values between transducer 1 and transducer 2 are outside the set tolerance. The transducer is defective?
                        : Error low pressure
error Er57
        The internal pressure failure triggered .. Check water level setting or the water supply!
error Er58
                        : Error dry run electronically
        The run-dry protection has tripped .. Check water supply!
                        : Error low water externally
error Er59
        The external low water protection has tripped .. Check water level setting or the water supply!
                         : Error dry run externally
error Er60
        The external dry-running protection has tripped .. Check water supply!
error Er61
                        : Error limit pressure
        The limit pressure is exceeded. Check system. Setting the limit pressure!
                         : Error Not stop (SMS)
error Er62
        The plant was set via SMS to emergency stop. A reset is only possible on the system
                        : Error lower limit
error Er63
        The set lower limit value is exceeded. Check system. Setting the limit!
error Er64
                         : External fault (Dig. Input)
error Er65
                         : Over-temperature control (Inverter)
        The control is too hot. Reduce carrier frequency. Cooling defective?
error Er66
                        : On / Off Inverter missing (software))
        Dig. Inverter input is missing, defective, or not configured. Call service!
error Er67
                         : Error Modem
        An error has occurred for a modem connection. Call service!
error Er68
                        : free
error Er69
                        : Error switching
        The switching frequency has been exceeded; stroke operation. Check non-return valves. Call service!
                         : Error maximum runtime
error Er70
        The maximum runtime is exceeded. Check the running time setting, or leakage, or non-return valves.
                        : Error submersible pump
error Er71
        The submersible pump monitor has tripped. Increase water consumption. Check non-return valves.
error Er72
                         : overheating cabinet
error Er73
                        : Temperature warning transducer 2
                                                                                   PTC
error Er74
                        : Error PTC tripping (software)
        The PTC thermistor has tripped. Reduce engine power. Improve cooling.
error Er75
                         : Error over temperature PT100 (Software)
                                                                                   PT100
        The PT100 has tripped. Reduce engine power. Improve cooling.
error Er76
                         : Error external motor protection
        External motor protection tripping. Reduce pump performance. Set motor protection!
error Er77
                         : Error failed main fuse
        External fuse failure. Check the main fuse!
                         : Error test run
error Er78
        The test run has not been completed without error. Check the system!
error Er79
                        : free
.
error Er80-85
                        : special error fire extinguishing systems
error Er90
                         : free
error Er91-Er99
                         : SW-ERR (Call customer service!))
```

9.3 Reset the daily hours of operation

To the daily operating hours (TLZ) to "0" to reset the following procedure: Go to the page "operating hours" and hold the SET / RESET button for about 10sec. pressed!

Messages in the display:	-	It appears this message after deleting the display
OPH Pump 1 1:17:08 DOH Pump 1 1:17:08 	SET/ RESET	OPH Pump 1 1:17:08 DOH Pump 1 0:00:00

If unsuccessful, repeat the process.

9.4 Reset the fault memory

To reset the fault memory, proceed as follows: Go to the page "error memory" and hold the SET / RESET button for about 60sec. pressed!





If unsuccessful, repeat the process.

9.5 Troubleshooting

The displays is dark

Mains voltage is present and turned on? If one or more fuses blown?

Plant does not start

The selector switch is not in operation! Set the selector switch to "Manual" or "Automatic"!

Is properly closed when operating from an external input cable?

It does not restart, even though the switch is set to "Automatic"...

Sensor not connected? (Message: "Sensor error")

The actual pressure is reached or exceeded the target pressure? The starting pressure is not set or too small? *Pumps do not switch to standby*

If the set pressure is set too high (pumps create the pressure does not)? Is the pipeline of investment not vented properly? Non-return valve incorporated in the pressure line upstream of the sensor?

Zero flow cutoff is not set correctly? See: cut-off, test mode, load factor, speed factor!

If the back-flow preventer leaking? In short rigid pipes, expansion vessel into the pressure line downstream of the back-flow preventer installed (pre-charge pressure check: starting pressure - 0.5 bar)!

Pressure indicator does not indicate the actual pressure

Pressure sensor type does not match the pressure sensor used (eg 10 bar - Sensor; 25 bar - sensor)?

Sensor or sensor plug is wet? Sensor cable is broken or connected incorrectly?

The control is too warm

Check ambient temperature! If necessary. provide cooling! Reduce carrier frequency! **Display shows no data and pump does not start**

Connected pumps have the "power" switch on already ground fault.

Check frequency without pumps connected to function

9.6 pump change

Which starts the pump first, is not defined. Master / Slave - To ensure smooth operation of the pumps every **300 minutes (999min adjustable 1 min)** - A change is operating. If a pump is stopped or fails because of a defect, the master status is indexed.

9.7 Forced pump change

For service purposes the pump change can be enforced by the respective master is stopped. By the stop of the master status on the next pump is advanced. Now you can proceed with the new master in the same way. The pump alternation is interrupted by the following criteria:

-The manual mode can be enabled with pump



-The programming process is not completed at a controller

-A pump is at fault.

10. Expert mode

The zero flow shut-off ensures safe shutdown output "0".

The zero flow cutoff requires when setting some experience and detailed knowledge of the operation of the controller. If the system with the factory setting of zero flow cutoff does not operate satisfactorily,

please contact your dealer or the manufacturer.The test phase:1 - 99%50%Recommendation: 50%.manipulates the desired pressure while the pump is operating to constantly check whether it delivers.The larger the test phase, the safer switches on the pump when pumping "0".

The speed factor:	1 - 99%	50%	Recommendation: 60%.
and the load factor :	1 - 99%	50%	Recommendation: 50%.

form a mathematical combination.

The logic of mathematical logic is to say: Actual pressure = set pressure + speed value <+ speed factor load value <= load factor standby.

This setting can be reproduced very well on the expert page. For the setting of the system with load and speed factor expertise is required!

Notice!

ī

example:

Pump operates at 45% load (LF). The rotational speed (DF) is 82%. The pressure is controlled. The test phase (T) increases with current value 78

Т	78	LF	45	50	
3.	00	DF	82	50	
Ρ1	.:	041H	z, 0	17,2A,	34C
P2	2:	000H	z, 0	00,0A,	29C

10.1 cutoff frequency

The cutoff frequency is the lowest operating frequency in the pressure control. If the cutoff frequency is reached, waiting for the pressure regulator to minimize delay from before the particular pump into "Standby" is activated. The cutoff frequency should be adjusted so that just no longer promotes the particular pump. The power-off should be set so that does not get the pump at this operating point to oscillate. This feature supports the zero flow cutoff.

10.2 expert site

The expert page helps in determining the speed and load factor:

Т	= Test phase value = 1-99	=	0,1 - 1 bar absolute,
LF	= Load factor current / comparison	=	values 0- 200% / Setting compared with 1-99%
DF	= Speed factor Current / comparison	=	values 0- 100% / Setting compared with 1-99%

P1/2 = Actual pump status: Output frequency, motor current, frequency temperature

T 000 = testing phase currently 0.00 = current pressure	T 00 LF 00 50 0.00 DF 00 50 P1: 000Hz, 000,0A, 27C P2: 000Hz, 000,0A, 29C	LF 00 = Current 50 = comparison DF 00 = Current 50 = comparison
T 075 = testing phase currently 3.92 = current pressure	T 75 LF 32 50 3.92 DF 78 50 P1: 039Hz, 011,2A, 32C P2: 000Hz, 000,0A, 29C	LF 32 = Current 50 = comparison DF 78 = Current 50 = comparison

10.3 Modbus register MARH- from Version 1.02 [5-145]

RegNo.	content	Cabinet number format and coding
0	Software-Version	
1	cabinet temperature	in °C
2	Status Flags	 1 = deviation between redundant transducers 2 = pressure / level - low water 4 = pressure / level - frequency limit active 8 = low water (external) 16,32 = transducer 2 disturbed 64 = fill mode active 256 = Temperature warning ext. 512 = Detected zero flow 1024 = Top pressure shutdown 2048 = Pressure reduction active 4096 = stopped plant (DG, GW) 8192 = Test run active
3	Error Flags	 1,2 = Main transducer open,Main Transducer defective 4.8 = transducer 2 open,Transducer 2 defective 16 = Error number of starts (leakage) 32 = dry run 64 = low pressure 128 = U-Pumpenwächter 256 = Max. Runtime 512 = limit pressure cut-off 1024 = Emergency stop (via GSM) 2048 = Over-temperature protection (*) 4096 = SW-Störung
10	Main transducer	e.g.: 478 = 4.78 bar oder 478 cm oder 4.78 °C
11	Besides transducer	e.g.: 478 = 4.78 bar oder 478 cm oder 4.78 °C
12	digital inputs	1=1.1.1, 2=1.1.2, 4=1.2.1, 8=1.2.2,, 64=1.4.1, 128=1.4.2
13	digital Outputs	1=0.1.1, 2=0.1.2, 4=02.1, 8=0.2.2,, 64=0.4.1, 128=0.4.2
14	Pump-states and manual switch	1=P1 Hand, 2= P1 Auto, 4=P1 active, 8=P1 Error 16=P2 Hand, 32= P2 Auto, 64=P2 active, 128=P2 Error
50	Operating mode	0=DR, 1=DF, 2=DG, 4=GW, 5=NF, 6=NL, 7=TH, 8=TK
51	Operating size 1	Top pressure (DR) or TO-pressure (GW) or
52	Operating size 2	Target pressure / stop pressure (DR) or TT-pressure (GW) or
53	Operating size 3	Start printing (DR) or UG-pressure (GW) or
54	Operating size 4	Differential pressure (DR) or LT-pressure (GW) or
55	Setpoint adjustment	At full load: 100 = 100%, 70 = 70%, 130 = 130%
56	overrun time	in seconds
57	limit delay time	in seconds
58	bridging time	in minute

Modbus-RTU interface (Slave)

characteristics

- Baud rate: 9600, 19200, 38400
- Modbus-Address: 1-250
- Parity and stop bits:

a)	,,N'' = no parity:	"8N2" (2 Stop bits)
b)	"U" = Odd parity:	"801" (1 Stop bit)
c)	$,,G^{"} = Even parity$	"8E1" (1 Stop bit)

Timing

- Response Time: Normal 50-200 ms (significantly longer during menu operation)
- There is a maximum answered one call per second

Modbus commands

- Currently only 03 = "Read Holding Registers"
- Number of simultaneously readable register = 6
- Example query: "01 03 00 32 00 06 64 07" (hex)
- (Device address 1, command 03, from register No. 50, read 6 pieces, CRC: 64 07)
- Sample answer: "01 03 0C 00 00 01 F4 00 C8 00 B4 00 14 00 64 4C 48" (hex)
- holding register 50 is 0 = operating mode "DR"
- holding register 51 is 500 = top pressure 5.0 bar
- holding register 52 is 200 = target pressure 2.0 bar
- holding register 53 is 180 = start pressure 1.8 bar
- holding register 54 is 20 = differential pressure = 0.2 bar
- holding register 55 is 100 = Set point adjustment: 100

10.4 SMS commands MAR / MARH- from Version 1.02 [5-148]

SMS commands the MAR / MARH - control mode "pressure, level, temperature":

commands	Send SMS → ©::
Status query	STATUS
system reset	RESET
Check values	WERTE
delete values	WRESET
Log on the system	ONLINE
Log off the system	OFFLINE
system emergency stop	NOTSTOPP
Start test run	TEST

SMS commands the MAR / MARH - control mode "Pressure control + limit":

commands	Send SMS → ©::
system start	START
Start system with setpoint 1	START S1
Start system with setpoint 2	START S2
Start system for 40 minutes	START T40
Start system for 40 minutes with setpoint 1	START S1 T40
Start system for 40 minutes with setpoint 2	START S2 T40
stop system	STOPP
system reset and start	RESTART
Status query	STATUS
system reset	RESET
Check values	WERTE
delete values	WRESET
Log on the system	ONLINE
Log off the system	OFFLINE
Start test run	TEST

commands	Send SMS → ©::
system start	START
system starting with 45Hz	START F45
Start system for 40 minutes	START T40
system starting with 45Hz for 40 minutes	START F45 T40
stop system	STOPP
system reset and start	RESTART
Status query	STATUS
system reset	RESET
Check values	WERTE
delete values	WRESET
Log off the system	ONLINE
Log off the system	OFFLINE
Start test run	TEST

SMS commands the MAR / MARH - control mode "+ Adjustable frequency limit":

SMS commands the MAR / MARH - control mode "Soft starter + limit":

commands	Send SMS → ©::
system start	START
Start system for 40 minutes	START T40
stop system	STOPP
system reset and start	RESTART
Status query	STATUS
system reset	RESET
Check values	WERTE
delete values	WRESET
Log on the system	ONLINE
Log off the system	OFFLINE
Start test run	TEST

11. Presentation menu MAR/MARH

Version 1.xx :

The arrow keys select the Functions (scrolling), input /

Modification of data.

The SET / RESET - button save entered data or acknowledgment ...

memorv Error memory / operating hours / cycles / etc. displays Main display + 4 + display pages provide clock set-points top pressure :99,99bar - 0,01bar-99,99bar (1-4) - 0,01bar-99,99bar (1-4) target pressure :04,00bar - 0,01bar-99,99bar (1-4) start pressure :03,50bar Different pressure :00,20bar - 0,01bar-99,99bar - 0 - 100 % / 0=Aus Set-point adjustment:0 :60s - 9s - 199s Limit delay time - 1 - 99Min Bridging time :1 :04,00bar - 0,01bar - 99,99bar (1-4) Stop pressure :03,50bar - 0,01bar - 99,99bar (1-4) Start pressure limits TO - Druck :04,00bar - 0,01bar - 99,99bar (1-4) TT - Druck (+) -0,01bar -09,99bar (1-4):00,50bar - 0,01bar - 99,99bar (1-4) LO - Druck :04,00bar -0,01bar -09,99bar (1-4)LT - Druck (-) :00,50bar - 0 - 100 % / 0=Aus set point adjustment:0 - 0s - 999s overrun time :5s - 9s - 199s limit delay time :60s - 1 - 99Min bridging time :1 times pressure reduction :0 - 0 - 100 % / 0=off Reduction time on :xx:xx clock - 00:00 - 23:59 clock Reduction time off :xx:xx clock - 00:00 - 23:59 clock :A - 10Uhr / 1Min / with manual frequency :10:00 clock - 00:00 - 23:59 Uhr :99s - 9s - 99s test run test time duration - Aus (off) / Ein (on) / expiration time Timer • A On time :xx.xx clock - 00:00 - 23:59 clock :xx.xx clock - 00:00 - 23:59 clock Off time expiration time :180Min - 0 - 999 Min base setting Number INV :1 - 0 - 2(4) :0 -0 - 2(4)Number FIX - AW-PW-AF-PF-J-B INU x :AW - AW-PW-AF-PF-J-B FIX x :0 Number of setpoints :1 - MAR-Input 1.1-S1 / Input 2.1-S2 Expansion vessel :N - Nein / Ja limit function :A - Aus / Ein Pump/Motor - P1 - P4 Read IN :P1 rotating direction :R - Right / Left Acceleration time :xx,0s - 0,01s - 99,9s / only manual operation - 0,01s - 99,9s / only manual operation - 0,01A - 199,9A Deceleration time :xx,0s : XAAA, : 400V rated current :xxx,0A rated voltage - 200V - 480V Nennfrequenz :050Hz - 1Hz - 200Hz :020Hz - 1Hz - 200Hz Min frequency :050Hz - 1Hz - 200Hz - 1Hz - 200Hz Max frequency Hand frequency :35Hz :50Hz - 1Hz - 200Hz Fix frequency Motor characteristic:K - Constant / quadratic / specific carrier frequency :9999Hz - 1000Hz - 9999Hz Vario - frequency - off / on :A motor protection - off / PTC / (PT100) :A Phase error output :A - off / on Transducer Sensor 1 :DE - off / on EDR 4-20mA - off / on EDR Sensor 2 4-20mA :A Sensor value 1 bar/m:010 - 0,0 - 99,99 Sensor value 2 bar/m:010 - 0,0 - 99,99 Sensor deviation :010% - 0% - 100% On Switch bar /m :1,50 - 0,00 - 99,99

- 0,00 - 99,99

	Ramp on bar /m	:1,80	- 0,00 - 99,99
	Ramp frequency	:50Hz	-030Hz - 200Hz
	Damp off bar /m	.1 0	
	Ramp oll bar /m	:1,0	- 0,00 - 99,99
	sensor input :mA	- m.	A / V / mA=MAR / V=FU MOD-Address 101
Contro	ller		
	PID P gain	•1.00	-0.01 - 9.99
	DID I time	.1,00	
	PID-I time	:1,00	- 0,1s - 9,99s
	Testing phase	:50%	- 1% - 100%
	Load Factor	:50	- 1 - 99
	Speed Easter	.50	_ 1 _ 00
	speed ractor		- 1 - 99
	Switch-off frequency	y:20Hz	- 1HZ - 200HZ
	Switch-off delay	:5s	- 1s - 99s
	switch-on delay	:1s	-1s - 99s
	Switcher time	.50	-1c - 0.00c
	SWILCHOVEL LINE		- 15 - 9,995
	Pump changeover time	e:300Min	- IMin - 999Min
safety			
_	limit pressure	:99.99bar	- 0.01bar - 99.99bar
	limit dolar	.300	- 10 - 000
	limit delay	: 308	- 15 - 995
	Auto Reset	:A	– Aus / Ein / 3x in 20 Min
	Safe Start	:E	- Aus / Ein
	Safe frequency	• 3547	- 25Hz - 200Hz
	Sare rrequency	. 55112	
	ary run	:E	- Off / On / < 0,5bar in 60s
	Under-pressure	:50%	- 0% - 100% 0% = off
	lack delav	:180s	- 1s - 999s delav
	aub amun auard	• 7	- off / On
	Sub. pump guard	• A	
	Guard frequency	:25Hz	- 25Hz - 200Hz
	Guard time	:99s	- 9s - 99s
	leakage control	:0	- 0 - 99
	Buntime control	.0	0 000 Min (0-off
	Runtime control	:0	= 0 = 999 MIN / 0 = 011
messag	es		
	inputs 1.1-4.2	:XXX	- no function
	inputs 1.1-4.2	:MSS /MSO	- motor protection (closer/opener)
	$\frac{1}{1}$	• 501	- sot-point 1 (closor)
	111puls 1.1 4.2	.501	set point i (croser)
	inputs 1.1-4.2	:502	- set-point 2 (closer)
	inputs 1.1-4.2	:WMS /WMO	- low water (closer/opener)
	inputs 1.1-4.2	:TRS /TRO	- dry run (closer/opener)
	$i_{nnut} = 1 - 1 - 1 - 2$	· ENE / ENO	- owtorp op $(off (Clocor/opener))$
	111puls 1.1-4.2	. LAL / LAU	- extern on /orr (croser/opener)
	inputs 1.1-4.2	:NAO	- Not-stop (opener)
	inputs 1.1-4.2	:RSS /RSO	- Reset multiple possible (closer/opener)
	inputs 1 1-4 2	• STS	- start/stop (only limit function)
		.010	Beteve Hend (also a (and a a))
	inputs 1.1-4.2	:EHS /EHO	- Extern Hand (Closer/opener)
	inputs 1.1-4.2	:TIS	- set timer (closer)
	inputs 1.1-4.2	:SRS	- start/stop/reset (only limit function)
	$\frac{1}{1-4}$	· 5D5	- Start/Stop (closer) switch Funktion
		.000	Start/Stop (closer) switcen runktion
	Inputs I.I-4.2	SPS ,	- Start/Stop (Croser) purse Funktion
	inputs 1.1-4.2	:SIS /SIO	- Failed main fuse (Closer/opener)
	inputs 1.1-4.2	:HRS /HRO	- Hunter relay only automatic (Closer/opener)
	inputs 1 1-4 2	·GES /GEO	- Limit Switches Fire Clear (Closer/opener)
	$\frac{1}{2}$	· ED1 4(2)	$\frac{1}{2} \frac{1}{2} \frac{1}$
	Inputs I.I-4.2	:EPI-4(Z)	= extern on / orr pump 1-4(2) (croser)
	inputs 1.1-4.2	:ZW1	- counter Eingang (closer)
	inputs 1.1-4.2	:ZW2	- counter Eingang (closer)
	inputs 1 1-4 2	• EAP	- On/Off Pump (Fermanox) (closer)
	1112465 1.1 1.2	• 10/11	on/orr ramp (rermanox) (eroser)
	outputs 1.1-4.2	:ALO /ALS	- alarm (closer/opener)
	outputs 1 1-4 2	·WMS	- low water (closer)
		. mpo	
	outputs 1.1-4.2	TRO	- dry run (opener)
	outputs 1.1-4.2	:DMS	- low pressure (closer)
	outputs 1.1-4.2	:NAS	- Refill function (closer)
	$\alpha_1 + \alpha_2 + \alpha_3 + \alpha_4 + \alpha_5 $	• C FC	- transducer error (closor)
	Julpuls 1.1-4.2		The share (show (closer)
	outputs 1.1-4.2	:AFO /AFO	- Fire alarm (closer/opener) no auto reset
	outputs 1.1-4.2	:PAO /PAS	- Pumps off (closer/opener)
	outputs 1.1-4 2	:LAS	- Run signal (Pump 1/2) (closer)
	-1 + -1 + -1 + -2	• BEC	- operating signal (closer)
	outputs 1.1-4.2	. DLO	operating signal (Closer)
	outputs 1.1-4.2	:FUS	- Ext.On/off FU1/2/3/4 (closer)
	outputs 1.1-4.2	:HZS	- heating (cabinet) (closer)
	outputs $1, 1-4, 2$.VRS	- cooling fan (cabinet) (closer)

alarm relay FU1-FUx : ALO / ALS - alarm (can be changed closer/opener)

commur	nication		
	Set-point	:I	- I-Intern / A-Analog / M -ModBus / G-GSM
	SD card	:A	- On / Off
	GSM / user Plant name Station number User 1 User 2 User 3 User 4 Bonus SIM - Card	: A : Irrigation : +491551234 : Off / On: : Off / On: : Off / On: : Off / On: : * 100 # : Prepaid /	- On / Off (for example) 56789 (for example) +49150123456789 (for example) +49160123456789 (for example) +49170123456789 (for example) +49170123456789 (for example)
	Modbus Slave	: A	- On / Off - see tab 10.2
Interr	ı		
	Overheating A temperature warning A	: 55 C : 45C	– 55 ° C – 70 ° C – 45 ° C – 50 ° C
	Ventilator On Ventilator Off Heating On Heating Off	: 35C : 30C : 5C : 10C	- 25°C - 35°C - 20°C - 30°C - 1°C - 15°C - 6°C - 20°C
	Sensor dev.	: 0.5 bar	- 0.1 bar - 9.9 bar
	frame	:A	- Aus / Ein
	Dynamic Threshold	:0%	- 0 - 100%
	Counter delay	:5s	- 1s - 99s
	SD-Version	:0	- 0 / S

MB-Debug-S

:0 - internal use only

13. customer settings MAR / MARH :

Sensor value 1 Sensor value 2	bar bar
Top pressure	bar
Target pressure 1 / Stop pressure 1 Start pressure 1 Differential pressure 1	bar bar bar
Target pressure 2 / Stop pressure 2 Start pressure 2 Differential pressure 2	bar bar bar
Set-point adjustment pressure reduction Reduction time on Reduction time off	1,00
rotating direction Acceleration time Deceleration time Motornennstrom carrier frequency rated frequency Min frequency Max frequency Hand frequency	seconds seconds A KHz Hz Hz Hz Hz Hz Hz Hz
Testing phase Speed Factor Load Factor Switch-off frequency Switch-off delay Switch-on delay Switchover time Pump changeover time	%%%%%Hzsecondssecondssecondsminute
limit pressure Safe frequency Safe Start dry run Under-pressure Lack delay	bar Hz minute % %
test time: duration: T.Intervall:	clock minute days
submersible pump guard Guard frequency Guard time	Hz seconds
leakage control Runtime control	minute