

MAR


1-2 pumps
pressure

Instruction manual
Type: MAR

Execution: pressure
S-No.: _____

System controller for 1- 2 pumps

Software version 2.03 (xxx) Stand 13.07.2020



Execution: pressure control
pressure switch
limit control
limit switch
level control
level switch
temperature controller
temperature switch
volume regulator
fluid flow regulator
vacuum regulator

Option: GSM /RS232

Inverter: E800

content

page

1. general information about the pump regulator	3
2. safety and warning instructions	3
3. Pump regulator	4
4. electrical connection	5
5. First switch on - Initial setup	7
6. panel description	8
7. clock, GSM, counter setting	11
8. menu operation	12
9. set points menu	13
10. Times menu	14
11. basic menu	15
12. pump / motor menu	17
13. transducer menu	19
14. controller menu	20
15. Safety menu	21
16. messages menu	23
17. communication menu	25
18. set phone book	26
19. internal menu (only for the manufacturer)	27
20. error messages	29
21. clear memory, change pumps	31
22. zero flow cutoff	32
23. SMS commands	33
24. transducer connection 4-20mA	35
25. customer settings	35

1. General information about the pump regulator

This product complies with the latest technology and is constantly being developed and improved. The device has undergone extensive testing after manufacture and therefore functions flawlessly. To ensure optimum function, read and observe this operating manual.

2. Safety and warning instructions

Before installing and commissioning the pump regulators, please read these operating instructions carefully and observe all warning and safety instructions. Always keep this manual in easy reach near the pump regulator.

definition



Warning !

Failure to observe the safety instructions can result in serious or even life-threatening bodily injury or substantial material damage!



Caution !

Failure to follow these instructions can result in serious or life-threatening bodily injury or material damage!



Notice !

Failure to follow these instructions may cause malfunction of the system!



The pump controller works with dangerous electrical voltages and controls dangerous rotating mechanical parts. The installation, commissioning and maintenance of this system may only be carried out by qualified personnel who are familiar with the operation. Be especially careful when automatic restart is activated. To prevent injuries due to possibly uncontrolled restarting of the motors after power failure, deactivate the automatic restart in case of doubt. During repairs or maintenance work, make sure that the system can not be switched on again by others! The built-in frequency converters have capacitors that carry dangerous high voltage even after switching off the power supply. Therefore wait at least 5 minutes after switching off the mains voltage before working on the device. Care must be taken that no live parts are touched. Do not work on the controller,

when mains voltage is applied. Earth the motors at the connections provided for this purpose.



If the provisions of the regional energy suppliers require a residual current device, it must be the on-site RCCB for frequency converter operation is an **all-current sensitive / selective RCD (RCD) circuit breaker type: B, B + with rated current 300mA**.



Make sure that the input voltage matches the voltage entered on the nameplate. All pump regulators are tested for dielectric strength and insulation resistance. Before the insulation measurement on the pump system, z. Eg during the inspection, the pump controller and the sensors must be disconnected!

The regulations of the electrical installation and the regional energy suppliers must be observed!

Environmental influences such as high temperatures, high humidity are to be avoided as well as dust, dirt and aggressive gases. The installation site should be well ventilated, not exposed to direct sunlight. Do not apply mains voltage to the sensor terminals or to the control terminals. Enter the operating signals Manual / 0 / Auto via the selector switch or via the control of the external contacts and not by switching on or off a mains or motor contactor. To ensure that your control system operates safely and reliably, all relevant safety regulations, such as: B. accident prevention regulations, regulations, VDE regulations, etc. are observed. Since these regulations are handled differently in the German-speaking countries, the user must observe the respective conditions applicable to him. The manufacturer can not exempt the user from the obligation to follow the latest safety regulations



The technical data and descriptions in this manual have been prepared to the best of our knowledge and belief. However, product enhancements are ongoing, so the manufacturer reserves the right to make such changes without notice. The manufacturer can not be held liable for errors in the operating instructions. Warranty is provided within the Federal Republic of Germany and within the statutory warranty period and applies only to the product itself and not for any consequential damage or damage or cost incurred by the occurrence of a warranty claim to others. Plants or system parts arise. The operator must in any case ensure that a failure or defect of the product can not lead to further damage.

3. Pump controller

This pump controller works as pressure controller fully automatically, depending on demand.

The speed of the pump (s) is infinitely variable with frequency converter operation. The actual value in the system is determined by means of a sensor. A PI controller adjusts the actual value to the set point. When operating with contactor or soft starter, the pump (s) are switched on and off as required. The pump controller can be parameterized and must be adapted to the respective operating conditions. The parameters are displayed in plain text. Commissioning is menu-driven. During commissioning, some data must be entered to ensure smooth operation of the system. It should be done by a knowledgeable person.

Advantages of pump control

- almost constant control value
- Continuous adjustment of pump performance to changing operating conditions
- Energy saving in frequency converter operation
- no integrated memory required for frequency converter operation
- less mechanical wear of the pumps

Design of the pump regulation

- the pump (s) must be designed according to the plant / requirement
- the integrating memory must be properly sized and set correctly.
- The pump (s) must have hydraulic capacity (s) of 10 - 20% in order to be able to control.
- For submersible pumps, the minimum frequency must be limited to 30..35Hz (Hydrodynamic bearing) (See information from the manufacturer of the engine.
- For underwater pumps a power reduction of approx. 5..10% can be assumed

Use of GSM monitoring



If you have installed a GSM modem (terminal), you can monitor the pump controller. Depending on the technical design, different commands are available to you. Make sure the antenna is well aligned for proper wireless network connection. Make sure that the power supply is always active together with the pump regulator. You need a registered SIM card. There are 3 users allowed as phonebook entry.

Installation and assembly of the controllers



Environmental influences such as high temperatures, high humidity are to be avoided as well as dust, Dirt and aggressive gases. The installation site should be a well-ventilated place not exposed to direct sunlight.



Due to the heat convection, the frequency converter controller must have at least Cm15 cm away from side walls or other facilities.

The permissible temperature range of + 5 ° C to + 30 ° C must not be fallen below or exceeded. Do not install the frequency converter controller near heat radiating equipment

Assembly of the pump control



Depending on the design of the control, a metal wall cupboard or a metal cupboard is built. The wall cabinet has 4 holes for wall mounting the control cabinet. For sole mounting stud bolts are recommended on which the control cabinet is hung. Mounting dimensions: See manufacturer data sheet The cupboard is delivered and set up with 200mm base. Pay attention to a secure position and ensure good ventilation on site. Mounting dimensions: See manufacturer data sheet

Construction of a control system with integrated storage tank (expansion tank)



A back flow preventer with spring force is absolutely necessary and can be installed in the suction line in front of the pump or in the pressure line behind the pump! If the check valve is installed in the suction line, an expansion vessel must be installed on the pressure side. Otherwise, an expansion tank can be installed if necessary.

the system is operated with an expansion vessel, the expansion vessel must be pre-pressed in the unpressurised state. The prepress pressure must be checked regularly.

The height of the prepress pressure is approx. ∴ start pressure minus 0.50 bar

Environmental conditions:



Ambient temperature:	+ 5 ° C - + 35 ° C
Humidity:	0- 95% non-condensing
Altitude:	1000m, 1% reduction / 100m
Vibration:	maximum 0.5g
Type of protection:	see type plate
Technical data:	see type plate


Construction of a pump system



A back flow preventer is mandatory and can be placed in the suction line in front of the pump or in the Pressure line to be installed behind the pump! If the back flow preventer is installed in the suction line, an integrated storage tank is required. Otherwise install an expansion vessel as required.

Examples:

1 flow direction	5 back flow preventer
2 regulator	6 pressure sensor
3 Motor	7 expansion vessel
4 pump	8 template tank



Operation of the pump system with integrated storage tank (expansion vessel)

If the system is operated with an integrated storage tank, the integrating storage tank must be pre-pressed in the unpressurised state. The prepress pressure must be checked regularly.

The height of the prepress pressure is: Starting pressure minus 0.50 bar.

Example:	set start pressure:	4.00 bar
	pre-press integrating storage to:	3.50 bar

Booster systems (DEA)



Booster systems are fully cased and wired pumping systems. With them, the installation effort is minimal - connection to the existing pipe network, mains voltage and commissioning. The controller is set at the factory for these systems.

These operating instructions refer only to the electrical control of the system, therefore, if necessary, consult the operating instructions of the pump (s).

4. Electrical connection of the controller



Make sure that the input voltage is on the nameplate registered voltage corresponds. Be sure to observe the supply voltage and terminal assignment!

The installation, commissioning and maintenance of the drives may only be carried out by a person skilled in the art of pumping.

Use shielded cable! Connect the shield to the earthing clamps in the control cabinet and to the pump!

For submersible motor pumps, connect the shield to ground potential near the pump.



Do not apply mains voltage to the sensor or control terminals.

Do not manipulate the sensor signal!

Do not connect other consumers to the 24V supply!

The used sensor 4..20mA, is connected to the respective terminals!

The respective pin assignment can be found in the wiring diagram.




All pump regulators use 4..20mA sensors.

The pin assignment can be found in the wiring diagram.

If the motor cable is longer than 50 meters, it is recommended to install a motor choke / sine filter.

Check the correct connection of the mains, sensor and control cables.

Set motor protection



The pump controller has a monitoring function for the motor current. The motor rated current when frequency converter operation is set in the menu. For designs with soft starter or contactor, the rated motor current is set on the motor protection relay or on the soft starter. See the respective operating instructions which are always enclosed with the documents.

Cable connection




The cable to the motor, the sensor cable and the cables for the external contacts must be provided with shielded cable (80%) and connected to the shielding brackets according to the opposite principle. If EMC cable glands are used, they must be connected to the screen according to the manufacturer's instructions.



Only with proper installation of the screen, a trouble-free operation is guaranteed! Umbrellas and earth are two different connections. Never use the shield as a grounding!

connection example



with shield bracket.

power connection



The pump regulators have a mains connection of 230 / 400V 50 / 60Hz or 230V 50 / 60Hz. See type plate of the pump regulator. Operating the controller with / without RCCB is of depending on the respective regulations. The protection takes place with fuses of characteristic C. The size of the fuse can be found on the rating plate of the pump regulator.

Digital inputs pump controller

Depending on the versions, different numbers of digital inputs are available. The digital inputs have their own potential with reference to "CO". It is used low voltage. When transferring signals from external systems, the potential must be disconnected via a relay contact. The digital inputs can be set as normally closed or normally open in the "Messages" menu and can be assigned different functions. Each function except "Reset" can only be assigned once. Functions see menu "Messages"

Digital outputs pump controller

Depending on the versions, different numbers of digital outputs are available. The digital outputs with orange terminals are floating relay outputs. The outputs may be charged with 24VDC-1A or 230VAC-1A. For signal transmission on external systems with high power, the potential must be implemented via a relay. The digital outputs can be set as normally closed or normally open in the "Messages" menu and can be assigned different functions. Each function can only be assigned once. If the total power of the controller is greater than 5.4kW, output 98 / N is always blocked for the panel fan. Functions see menu "Messages"

Digital frequency inverter outputs

For controllers with frequency inverters, depending on the version, there are different numbers of converter relays available. These relay outputs are not always routed to the terminal block. The inverter relays are potential-free and may be charged with 24VDC-1A or 230VAC-1A. For signal transmission to external systems with high power, the signal must be implemented via a relay. The inverter relays can be set as normally closed or normally open in the "Messages" menu and can be assigned different functions. Each function can only be assigned once. Functions see menu "Messages"

Analog inputs (transducer)

Depending on the versions, different numbers of sensor inputs are available. The analog inputs have their own potential. The signal is always 4-20mA. Only passive sensors with 24VDC supply can be used. If active sensors are to be used, our converter "HO.xx" must be used. For long sensor lines or for signal transfer from external systems, the signal must be disconnected via a potential converter. Each function can only be assigned once. Functions see menu "Basic" + "Sensor"

motor connection



The motor must be connected according to the output voltage. See type plate of the pump regulator. Clamp the motor on star or triangle. See nameplate of the engine. The direction of rotation of the motor determines the frequency converter. Direction of rotation can be set in the "Motor" menu. For controls with soft starter or contactor, the direction of rotation must be adjusted by reconnecting. Depending on the design of the control, PTC thermistors can be connected. Before switching on the mains voltage again check all connections for correctness!

5. First switch on - Initial setup

Example: double system

At power-up, the controller initializes

MAT ▲▼
V2.xx (xx.x) SN. xxxxx
MAR

>

Init: (2 FU)
FU 1 : OK, old
FU 2 : OK, old

>

Main display after initialization

00,28 bar off P1
off P2
P1: 000Hz, 000,0A
P2: 000Hz, 000,0A

If the initialization goes wrong, there is an error message. With ER101 the frequency inverters can not be reached. Check the Modbus connection / mains voltage of the frequency inverter.

Main display error ER

00,28 bar ER101 P1
ER101 P2
P1: FU ERR
P2: FU ERR

The system is now set to "AW" = active change.

If the system setting is to be changed, this must be done in the base menu.

5.1 Switching on the system after changing the frequency inverter

Example: Double system with new INV 2

At power-up, the controller initializes

MAT ▲▼
V2.xx (xx.x) SN. xxxxx
MAR

>

Init: (2 FU)
FU 1 : OK, old
FU 2 : OK, new

>

INU 2 : factory setting ?
.....

Attention ! Confirm within 20s, otherwise the frequency converter will not be parameterized!

INU 2 : factory setting ?
.....
SET

Confirm the factory setting with the



"Set" button


OK !

Main display after commissioning.

00,28 bar off P1
off P2
P1: 000Hz, 000,0A
P2: 000Hz, 000,0A

6. panel Description

Control panel with four -line **LCD display** for parameters and operating data:



The backlight can be switched off with a delay.



The **arrow keys**

Select the functions (scrolling),
Enter / change data.



The **SET / RESET - keys**

Storing input data,
Error acknowledgment

The red LED flashes when warning.







The green LED flashes with inactive control

The red LED will light up if a fault occurs.

The green LED is lit when the control is active.

Display with different symbols and values

Active main display with "external" / "internal" setpoint specification status



These icons are displayed depending on the function in the display.



GSM is active: A mobile network connection exists



GSM is inactive: There is no mobile network connection.

In addition, the alarm lamp lights up and the display shows "no mains".




Analog set point: The set points are specified via the "Poti" input.

operating displays

Display: status, pressure, speed, current or active / inactive


Pumps off



Manual operation (Hand)



Automatic operation (Auto)



Select operating displays




With the ▲ arrow key, the next screen is displayed.
Pressing the same arrow key the next screen is displayed.
Use the ▼ arrow key, the previous screen is displayed.

If the display is "hours of operation" is displayed and the ▲ arrow key is pressed, so you get to the error memory.


From the fault memory of the SET / RESET button must be pressed to return to the initial display.

active message

Operating Status: time, pressure, frequency, current P1-xx ... , equipment temperature




Expert site::




memory messages

Memory status: Hour meter BST: P1-Px

Memory status: day run - counter TLZ: P1-Px



Fault memory: 1 - x with date stamp P1 - P3 last 1-16 error. For each error, the pressure and pump status are stored on an extra page. Switch over by pressing the SET button for 2 seconds




Between the displays operation can be changed with the arrow keys ▲ and ▼.

Information displays


Pumps off

The MA controller is switched off. The message "Pump Off".




External off

The MA controller is connected via an external input. If the connection is open, the message "External Off" appears. The respective pump (s) are stopped. The red LED lights. The alarm relay is not activated.




External low water

The MA controller is connected via an external input. If the connection is open, the message "low water" will appear. The respective pump (s) are stopped. The red LED lights. The alarm relay switches.




Fill in active

If the "under-pressure" to be active, the MA-regulator is operated in fill mode until the pressure for the first time is balanced. The red LED lights. The alarm relay is not activated.




Safe Start is active

If the function "Safe Start" to be selected, the MAR controller is operated in fill mode. The master pump is active. The slave pump (s) is inactive. The red LED lights. The alarm relay is not activated.




Top pressure

The current pressure is above the set upper pressure. The MA controller controls off to prevent a further rise in pressure. It appears the message "top pressure". The red LED lights. The alarm relay is not activated.



Stopped plant

The MA-controller is connected via an external emergency stop. It appears the message "Stopped plant". The pump (s) are stopped. The red LED lights. The alarm relay switches. "Restart" via GSM or reset - function.



7. Clock, GSM, counter set












Set time / date:

Press **SET / RESET button** for 5 seconds at the operating display time / date.

If the cursor is flashing, the time and date using the

Arrow ▲ button, arrow ▼ button and the **SET / RESET button** can be set.

After confirming "OK", the change is adopted.

  	  	  
Monday Auto P1 14:59:17 Auto P1 16.01.17 S/W - A P1: 048Hz, 015,0A P2: 000Hz, 000,0A	Monday Auto P1 14:59:17 Auto P2 16.01.17 S/W - A P1: 048Hz, 015,0A P2: 000Hz, 000,0A	Monday Auto P1 15:59:17 Auto P2 16.01.17 S/W - E P1: 048Hz, 015,0A P2: 000Hz, 000,0A OK  















Set GSM users:

You can use the "Communication" menu, activate a GSM modem

and set in the phonebook, the system and the user and provide input or output.

On this page you can change the Contract, see the signal strength (0-30), to interrogate their accounts and each user (Be.x) "A" or turn "off". When the credit card contract is always at € 99.99.

If the cursor is flashing, the value using the **arrow ▲ button, arrow ▼ button** and the **SET / RESET button** can be set. After confirming "OK", the change is adopted.












  	  	  
contract : P S 20  credit : 15,25€ Be.1 : E Be.2 : E Be.3 : E	contract : P S 20  credit : 15,25€ Be.1 : E Be.2 : E Be.3 : E	contract : P S 20  credit : 11,85€ Be.1 : A Be.2 : E Be.3 : E OK  

Set External Counter / Counter Delay:

You can configure via the menu "Messages" inputs as counter

To put the meter on, press **SET / RESET button** for 5 seconds when displaying water meter.

If the cursor is flashing, the value using the **arrow ▲ button, arrow ▼ button** and the **SET / RESET button** can be set. After confirming "OK", the change is adopted.

  	  	  
Water counter: Z1 / 1000l : 154 sqm Z2 / 100 l : 100.0 sqm Counter Delay : 5s	Water counter: Z1 / <u>1000l</u> : 154 sqm Z2 / 100 l : 100.0 sqm Counter Delay : 5s	Water counter: Z1 / 1000l : 154 sqm Z2 / 100 l : 100.0 sqm Counter Delay : 5s OK  

Reset the counter:

To reset the counters to "0", the following procedure:

Go to the page "water meter" and hold the **SET / RESET button** for about 10sec. pressed!


Between the displays operation can be changed with the arrow keys **▲** and **▼**.

8. Menu operating

Set values

Example set points

setpoints
times
base setting
pump/motor
transducer
controller
safety
messages
communication
intern




By pressing the - button for 5 seconds, the menu can be interrupted.

Password Code: xxx

Parameter: xx.xx bar

save: Yes / No



Operation of the menus is the same for everyone.
When saving the values, the system queries whether the values for P1, P2, ...
or stored for all pumps.

9. Adjust set-points

set-points

top value : <u>05,00bar</u> setpoint : <u>04,00bar</u> Start difference : <u>00,50bar</u> overrun time : 5s	top value : <u>05,00bar</u> setpoint : <u>04,00bar</u> Start difference : <u>00,50bar</u> difference value : <u>00,10bar</u> overrun time : 5s
top value : <u>05,00bar</u> setpoint : <u>04,00bar</u> Start difference : <u>00,50bar</u> difference value : <u>00,10bar</u> overrun time : 5s	top value : <u>05,00bar</u> setpoint 1 : <u>04,00bar</u> Start difference 1 : <u>00,50bar</u> setpoint 2 : <u>04,00bar</u> Start difference 2 : <u>00,50bar</u> difference value : <u>00,10bar</u> overrun time : 5s

Password Code: xxx

Parameter: xxx.xx

save: Yes / No



The set-points are set for the plant.

Adjust pressure regulator set points

Pressure regulator 1 set point

top value : <u>05,00bar</u> setpoint : <u>04,00bar</u> Start difference : <u>00,50bar</u> difference value : <u>00,10bar</u> overrun time : 5s
--

Pressure regulator 2 setpoint 2

top value : <u>05,00bar</u> setpoint 1 : <u>04,00bar</u> Start difference 1 : <u>00,50bar</u> setpoint 2 : <u>04,00bar</u> Start difference 2 : <u>00,50bar</u> difference value : <u>00,10bar</u> overrun time : 5s
--

Pressure regulator analog set point

top value : <u>05,00bar</u> analog value : <u>04,00bar</u> Start difference : <u>00,50bar</u> difference value : <u>00,10bar</u> overrun time : 5s
--

Pressure switch 1 set point

top value : <u>05,00bar</u> stop value : <u>04,00bar</u> Start difference : <u>00,50bar</u> difference value : <u>00,10bar</u> overrun time : 5s
--

Pressure switch 2 set point 2

top value : <u>05,00bar</u> stop value 1 : <u>04,00bar</u> Start difference 1 : <u>00,50bar</u> stop value 2 : <u>04,00bar</u> Start difference 2 : <u>00,50bar</u> difference value : <u>00,10bar</u> overrun time : 5s
--

Pressure switch analog set point

top value : <u>05,00bar</u> analog value : <u>04,00bar</u> Start difference : <u>00,50bar</u> difference value : <u>00,10bar</u> overrun time : 5s
--

Explanation of parameters:

Enter the top value value at which the system will be governed immediately.

top value :05,00bar - 0,01bar - 99,99bar (1-4)

Enter the set point or stop value with which the system should work.

Attention ! With analog value specification nothing can be set here! Here, the current set point is only displayed!

set point/ Stop value :02,00bar - 0,01bar - 99,99bar

Enter the start difference value at which the system will start again after the "Standby"

Start difference :00,50bar - 0,01bar - 99,99bar

Enter the differential value at which the next pump will be switched on.

differential value :00,10bar - 0,01bar - 99,99bar

Enter the delay time until the pump to stop.

overrun time :5s - 0s - 999s

10. adjust times

times

reduction	: 000%
reduction time on	: 20:00h
reduction time off	: 23:00h
test time	: 10:00h
duration	: 99s
Test interval	: 0 days
timer Function	: A
expiration time	: 10 Min
*weekdays	: S _ _ _ _ F _
*time 1 on	: 10:00h
*time 1 off	: 14:00h

Password Code: xxx

Parameter: xxx.xx

save: Yes / No



The times are set for the plant.

Explanation of parameters:

If necessary, select the pressure reduction for the pump on time.

This function gives you the possibility to reduce the energy consumption of the pump.

reduction	:0	- 0 - 100 % / 0=off
reduction time on	:xx:xx h	- 00:00 - 23:59 h
reduction time off	:xx:xx h	- 00:00 - 23:59 h

Select the test run (e.g., fire extinguishing) for the pump. This feature gives you the option of running the pump once a day at hand frequency in 24 hours. This function can prevent the pump from seizing.

test time	:10:00h	- 00:00 - 23:59 h
duration	:20s	- 0 - 999s with manual frequency
T.Interval	:0 days	- 0 - 30 days (0 days = Off)

If necessary, select the timer function T or N. This function gives you the opportunity to operate the system for a short time or with an after-run.

Timer function	: A	- (A) Off, timer without function
	: T	- the expiration time is active when the system is started..
	: N	- the expiry time is active as soon as the system is started and goes into "standby" mode (follow-up time).



With an additional button "Set timer", which is activated via a digital input "TIS", the set time can be counted up. Example: Expiry time T = 10min. Press the button briefly: new time: 20min. By holding down the key for a longer time, the timer value is reset to the basic setting, e.g. 10min. set back.

The set time is only ever active once.

Thereafter, the expiry time set in the menu is always active again.

expiration time : 10 Min


If necessary, select the timer function E. This function allows you to control the system in time with day of the week and two times

timer Function	: E	- (E) On, facility works with weekday, time 1 + time 2
weekdays	: S _ _ _ _ F _	- S M T W T F S, adjustable, Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday. with the arrow ▲-button , arrow ▼-Taste adjustable.
time 1 on	: 10:00h	- 00:00h -23:59h , adjustable
time 1 off	: 14:00h	- 00:00h -23:59h , adjustable

11. Base Setting

Base Setting

number INV	: 2
number FIX	: 0
INV 1	: AW
INV 2	: AW
setpoints	: 1
operating mode	: DR



Password Code: xxx

Parameter: xxx.xx

save: Yes / No



2x FIX

number INV	: 0
number FIX	: 2
FIX 1	: AW
FIX 2	: AW
setpoints	: 1
operating mode	: DR

1xINV+1xFIX

number INV	: 1
number FIX	: 1
INV 1	: AW
FIX 1	: AW
setpoints	: 1
operating mode	: DR

2xINV JO+AW

number INV	: 2
number FIX	: 0
INV 1	: JO
FU 2	: AW
setpoints	: 1
operating mode	: DR

2x FIX AW+BO

number INV	: 0
number FIX	: 2
FIX 1	: AW
FIX 2	: BO
setpoints	: 1
operating mode	: DR

1xINV+1xFIX AF+AF

number INV	: 1
number FIX	: 1
INV 1	: AF
FIX 1	: AF
setpoints	: 1
operating mode	: DR

1xINV+1xFIX JO+AW + value3

number INV	: 1
number FIX	: 1
INV 1	: JO
FIX 2	: AW
setpoints	: 3
operating mode	: DR

Explanation of parameters:

Enter the number of frequency converter (INV) pumps.

number INV :1 - 1 - 2

Enter the number of direct (contactor / softstarter) (FIX) pumps.

number FIX :0 - 0 - 2









Enter the function of the respective frequency converter pump.

INV x :AW - AW

Enter the function of the respective direct (contactor / softstarter) pump.

FIX x :AW - AW

Meaning of the abbreviation:

	JO	= Jockey pump in the system	first pump in the system in fixed position with shutdown and transfer to the first system pump. Only selectable once. (only INV)
	JR	= Jockey pump in the system	first pump in the system in fixed position with shutdown,, Handover and return to the first system pump. Only selectable once. (only INV)
	*SP	= Suction pump in the system	first pump in the system in fixed position only together with one or more system pumps. Running time limitation possible. Only selectable once. (Contactor, soft starter)
	AW	= Work pump in the system	active pump in the system with interchangeable system pump (contactor, soft starter, INV)
	PW	= Work pump in the system	passive pump in the system for the change pump with power limitation of the plant
	AF	= Work pump in the system	active pump in the system with fixed position System pump (contactor, soft starter, INV)
	RF	= Work pump in the system	Reserve pump in the system as a revere for change / fix pump.
	BO	= Booster pump in the system	last pump with system in fixed position with switching on and off. Only selectable once. (Contactor, soft starter, INV)

Enter the number of the set-points, at which the system is to operate.

Number of set-points :1/2/3/5 - 1 = one set point, 2 = two set points, 3 = set points 1x jockey + 2x AW

Depending on the version, not all operating modes can be set.

Select the operating mode of the system.

operating mode :DR - DR

DR	=	Pressure	The system works as a pressure regulator / pressure switch (bar)
DF	=	Pressure + fire mode	The system works as a pressure regulator / pressure switch (bar) with the special function fire extinguishing (only MARH)
DG	=	Pressure + Limit	The system works as a pressure regulator / pressure switch with restart interlock (bar)
DD	=	differential pressure	The system works as a differential pressure controller with two sensors (bar)
TH	=	Heating	The system works as a temperature controller / temperature switch (°C)
TK	=	Cooling	The system works as a temperature controller / temperature switch (°C)
TD	=	Difference temperature	The system works as a differential temperature controller with two sensors (°C)
NF	=	Level filling	The system works as a level controller / level switch (cm)
NL	=	Level empty	The system works as a level controller / level switch (cm)
VR	=	Vacuum	The system works as a vacuum regulator (mbar)
VD	=	Difference vacuum	The system works as differential vacuum regulator (mbar)
ME	=	Volume	The system works as a flow regulator (l/min)
ST	=	Flow	The system works as a flow controller (%)
GW	=	Limit control	The system operates as a limit value Control with / without adjustable speed with restart interlock (Hz) (rpm)
FU	=	frequency inverter	The system works as a motor controller with fixed or adjustable speed with external release (Hz) (rpm)


If required, switch on the limit value function for irrigation systems.

If the limit value function is active, the system switches off and must be restarted with the external command.

12. Set electric pump / electric motor

Pump/Motor/ inverter

Read INV	: P1
rotating direction	: R
acceleration time	: 01,0s
deceleration time	: 02,0s
Rated current	: 008,0A
rated voltage	: 400V
rated frequency	: 050Hz
min frequency	: 020Hz
max frequency	: 050Hz
hand frequency	: 035Hz
fix frequency	: 040Hz
switch-off frequency	: 035Hz
load factor	: 050%
speed factor	: 050%
Characteristic	: K
Boost	: 04%
carrier frequency	: 5000Hz
vario - carrier frequency	: A
Motor protection	: A
sine filter	: A
phase guard output	: A



Password Code: xxx



Parameter: xxx.xx

save: Yes / No

Explanation of parameters:

Select whether you want to read the data from the respective frequency inverter.

read INV :P1 - P1 / P2 / P3 / P4

Enter the rotation direction of the pump (s). AC phase angle does not matter!

rotating direction :R / L - Right / Left

Enter the Acceleration time of the pump (s). Recommendation: 1-3 seconds.

acceleration time :03,0s - 0,01s - 99,9s / only manual operation

Enter the deceleration time of the pump (s). Recommendation: 2-10 seconds.

deceleration time :05,0s - 0,01s - 99,9s / only manual operation

Enter the motor rated current of the pump (s). Data: See nameplate.

rated current :xxx,0A - 0,01A - 199,9A

Enter the motor voltage to the pump (s). The setting they found on the nameplate of the motor.

rated voltage :400V - 200V - 480V

Enter the rated frequency of the pump (s). Data: See nameplate. With this function, the nominal frequency of the pump is set.

rated frequency :50Hz - 1Hz - 200Hz

Enter the minimum frequency of the pump (s). This feature gives you the option of the minimum frequency of the pump for operation entered. This way of setting the pump power can be limited.

min frequency :25Hz - 1Hz - 200Hz

Enter the maximum frequency of the pump. This feature gives you the option to enter the maximum frequency of the pump for operation. This way of setting the pump power can be limited.

max frequency :50Hz - 1Hz - 200Hz

Enter the hand frequency in Hz, a hand, in which the respective engine in manual mode is to move up and down..

hand frequency :35Hz - 1Hz - 200Hz

Enter the fixed frequency for the respective pump with the limit switch is to operate. This rate can be expressed by SMS - command (option) for the current operation to change. If a SMS - start command sent without a value, the system works with the fixed frequency.

fix frequency :40Hz - 1Hz - 200Hz

Enter the switch-off frequency for the respective zero-flow shut-off pump.

switch-off frequency (local) :35Hz - 1Hz - 200Hz

Enter the load factor for the null sets shutdown. Recommendation: 50%. See also "zero flow cutoff"

load factor (local) :50% - 1% - 100% from Inverter

Enter the speed factor for the null sets shutdown. Recommendation: 50%. See also "zero flow cutoff"

speed factor (local) :50% - 1% - 100% from Inverter

Select the motor characteristic (Constant / quadratic / specific) of the pump. With this function, the power consumption of the pump can be changed. Recommendation: Square for centrifugal pumps; constant for submersible pumps; specifically at frequency inverter problems.

motor characteristic :K - Constant / quadratic / specific

Enter the value of the boost pump (s). This function is needed to better run the pump for heavy start-up.

Boost :04% - 00% - 20%

Enter the carrier frequency of the pump (s). Low carrier frequencies result in higher engine noise. This function is used to tune the carrier frequency to use with different cable lengths between pump and drive.

carrier frequency :5000Hz - 2000Hz - 9999Hz

Select the Vario - carrier frequency of the pressure control. The Vario - carrier frequency cause changes in engine noise to the soundscape for people to improve.

vario - carrier frequency :A - off / on

Select the motor protection function.

motor protection :A / K - off / PTC / (PT100)

Set the Sinus Filter function if it is installed between the controller and the pump.

sine filter :A / E - (A) off// (E) on

Sine filters are switched in the (motor) line between inverter output and motor. Especially with long motor cables, sine-wave filters are used to reduce parasitic conduction capacitances. If the LC filter is dimensioned appropriately, the pulse width modulated (PWM) output voltage of the frequency converter is converted into a sinusoidal voltage.

Each sine-wave filter has a frequency working range. This work area must be kept, so that the sine filter does not burn. The sinusoidal filter function must therefore be switched on in the motor menu if a sine-wave filter is installed. This prevents the frequency converter from lowering its clock speed at higher temperatures.

Many manufacturers of submersible motors require sinus filters. Sinusoidal filters generate noise, so that a permanent work in the environment is not possible.

Motor reactors are generally switched to the (motor) line between the inverter output and the motor. They are intended to reduce the noise emissions of the motor cables and to limit the voltage peaks caused by the inverter clock frequency. In addition to improved EMC, it is important to protect the engine and also to achieve a reliable operating behaviour. Motor chokes generate noises, so that a permanent work in the environment is not possible.

Each motor reactor has a frequency workspace. This work area must be maintained so that the motor choke does not burn. The sine filter function must therefore be activated in the motor menu if a motor choke is installed. This prevents the frequency converter from lowering its clock speed at higher temperatures.

Select the phase failure detection output of the pressure control. The phase failure detection protects the motor against cable interruption.

phase guard output :A - (A) off// (E) on

13. Adjustment of transducer

Transducer

Main sensor	: S1
Sensor range	: 10,00bar
Main sensor offset	: 00,00bar

Password Code: xxx

Parameter: xxx.xx

save: Yes / No



The set points change after sensor range change !

S1= Sensor 1,

Main sensor function: This function is determined by the basic setting of the system.

Main sensor pressure 16 bar

Main sensor	: S1
Sensor range	: 16,00bar
Main sensor offset	: 0

Main sensor z.B: S1 pressure 10 bar

Main sensor	: S1
Sensor range	: 10,00bar
Main sensor offset	: 0

Main sensor z.B.: S3 pressure 16 bar Offset 1 bar

Main sensor	: S1
Sensor range	: 02,50bar
Main sensor offset	: 01,00bar

Main sensor z.B: S3 pressure 10 bar

Main sensor	: S1
Sensor range	: 10,00bar
Main sensor offset	: 0

Explanation of parameters:

Enter the sensor input for the main sensor. Main sensor can be any existing sensor.

Main sensor : S1 - S1 - S2 - S3 (function of the main sensor: basic setting)

Set the sensor measuring range. Data: See nameplate sensor.

Sensor range :16,00 - 0,00 - 99,99

Enter the offset from the sensor.

Main sensor Offset :00,00 - 0,00 - 99,99

14. adjust controller

controller

PID P gain	: 0,50
PID-I time	: 0,50s
control ramp	: 1,0s
Actual value tolerance	: 01%
set point adjustment	: 1,00
testing phase	: 050%
switch-off delay	: 02s
switch-on delay	: 01s
switchover time	: 5s
pump changeover time	: 300Min
Standby	: E
top value	: 15%
top value time	: 20s
switch-off frequency	: G
load factor	: 050%
speed factor	: 050%
switch-off frequency	: 035Hz




The rule values are set
for the plant

Password Code: xxx

Parameter: xxx.xx

save: Yes / No



Explanation of parameters:

Enter the PID P gain of pressure control. Ensures the rapid adjustment of the pump to the desired value.

PID P gain :0,50 - 0,01 - 9,99

Enter the integration time of the PID controller. Ensures the rapid adjustment of the pump to the desired value.

PID-I time :0,50s - 0,1s - 9,99s

Enter the control ramp of pressure control. The regulation changes the ramp adjustment of the pump.

control ramp :1,0s - 0,1s - 99,99s

Enter the setpoint tolerance for zero amounts shutdown.

Actual value tolerance :01% - 0% - 10%

Enter the set-point adjustment, in which the target pressure should be adjusted to the pipe.

Small 1 = target pressure drop; Larger 1 = target pressure increase.

set point adjustment :1,0 - 0,2 - 2,0 / 1,0=Aus

Enter the Testing phase for the null sets a shutdown. Recommendation: 20%. See also "zero flow cutoff"

testing phase :20% - 1% - 99% = 0,1 - 0,99bar absolute

Enter the time delay for the zero quantities shutdown.

switch-off delay :2s - 1s - 99s

Enter the time delay for the zero quantities shutdown.

switch-on delay :1s - 1s - 99s

Enter the changeover time for the gentle pump change a

switchover time :5s - 1s - 19s

Enter the operating time until the pump change.

pump changeover time :300Min - 1Min - 999Min

Enter the standby function. (Stop when the controller is balancing or basic speed)

Standby :E - E(on) / A(off)

The electronic protection monitoring for dry running. Special function in target guardian.

top value :25% - 0% - 50% (0% = off)

top value time :20s - 1% - 99%

Set the cutoff frequency to global (same for all pumps) or to local (for all pumps individually)

switch-off frequency :G - (G) global / (L) local

Enter the load factor for the null sets shutdown. Recommendation: 50%. See also "zero flow cutoff"

load factor (global) :50 - 1% - 99% from Inverter

Enter the speed factor for the null sets shutdown. Recommendation: 50%. See also "zero flow cutoff"

speed factor (global) :50 - 1% - 99% from Inverter

Enter the cutoff frequency for the zero quantities shutdown.

switch-off frequency (global) :35Hz - 1Hz - 200Hz

15. Setting the safety

Safety only with the main transducer

Sensor limit	: 95%
Limit delay off	: 30s
Auto Reset	: A
Safe Start	: 0Min
Safe frequency	: 35Hz
dry run	: A
dry delay off	: 010s
low water	: A
water delay off	: 010s
water delay on	: 003s
flow shortage	: A
flow delay off	: 180s
maximum detector	: O
maximum delay	: 180s
pressure monitor	: K
pressure monitor	: 50%
pressure delay off	: 180s
submersible pump guard	: A
Guard frequency	: 30Hz
Guard time	: 30s
leakage control	: 0
Runtime control	: 0Min

Password Code: xxx

Parameter: xxx.xx

save: Yes / No



Maximum detector main sensor

A = off No function

O = regulate only for automatic / top value function

Pressure monitor main sensor

A = off No function

E = on only active in automatic mode

I = always active with automatic and manual

K = Complete with automatic and manual active plus electronic dry run (<0.5bar in 30s)

Explanation of parameters:

Enter the sensor limit value for the MA controller as well as the delay time at which the system is to switch off.

Sensor limit value monitoring is always active.

Sensor limit :95% - 1% - 99% **100% = protection > 20mA off**

Limit delay off :30s - 1s - 99s

Select the reset function for the MA-regulator. This feature gives you the option at fault automatically to let

3 times in 20 minutes, start up again. **Note: The system restarts automatically!**

Auto Reset :A - A(off) / E(on) / 3x in 20 Min

If necessary, select the security start for the MA-regulator. If the Safe Start is selected, the pipe is after turning on the power or after a power failure, slowly and gently to fill. The Safe Start mode, only one pump operates at fixed speed for the time set. The next pump (s) is (are) stopped.

This function should be set by an expert, or after consultation with the manufacturer.

Safe Start :0 - 0 - 99 Min 0 Min = off

Safe frequency :35 - 0 -200Hz

If necessary, select the dry run protection, in which the system will shut down when running dry.

If the pressure / level below or the corresponding digital input is operated, shut down due to "dry run".

If "Always" is selected, the dry run is also active in manual mode. No automatic restart after dry run!

dry run :A - A(off) / E(on)

dry delay off :10s - 1s - 999s

If necessary, select the low water protection, in which the system will shut down if the water shortage.

If the pressure / level below or the corresponding digital input is operated, shut down due to "low water". If "Always" is selected, the water shortage is also active in manual mode. Automatic restart after water shortage.

low water	:A	- A(off) / E(on)
low delay off	:10s	- 1s - 999s
low delay on	:10s	- 1s - 999s

If necessary, select the flow shortage - protection, in which the plant is shut down for lack of flow.

If the flow falls below or operated the corresponding digital input is switched off due to "lack of fluid". If "Always" is selected, the flow shortage is also active in manual operation. No automatic restart after flow shortage!

flow shortage	A	- A(off) / E(on)
flow delay	:180s	- 1s - 999s

If necessary, select the maximum detector function. The maximum detector is only active in "Auto" mode!

maximum detector	: O	- A / S / W / O
maximum delay	: 180s	- 1s - 999s

A = off;	the maximum detector is out of order No Text
O = top value;	when the upper value is reached, the system is immediately de-regulated. Text "top value"

Enter the% value of the pressure monitoring, in which the system will shut down if the pressure deficiency. The% value refers to the set pressure value. Example: 50% of 4.0 bar. The under-pressure is from <2.0 bar active and switches to 3 minutes delay the pump.

If "0%" is set, the under-pressure monitoring is disabled.

In addition, the electronic protection against dry running, in which the system will shut down if the dry run, are elected to do so.

If the pressure of at least 0.5 bar is not reached after 30 seconds, it will shut down due to "dry run".

The dry run is also active in manual mode. No automatic restart after a under-pressure / dry run !

pressure monitor	:K	- A(off) / E(On) / I(always) / K(Complete)
-------------------------	----	--

pressure monitor	:50%	- 0% - 100% 0% = off
pressure delay	:180s	- 1s - 999s delay

A =	off	low- pressure has no function
E =	on	low- pressure is active in automatic
I =	always	low- pressure is active in automatic and manual
K =	Complete	low- pressure is in automatic and manual active plus electronic dry run (<0.5 bar in 30s)

The submersible pump guard ensures the safe shutdown of the pump at low speed. The function is important to protect submersible motors. Turn the U-pump guard with a submersible pump operation.

submersible pump guard	:A	- A (off)/ E (On)
Guard frequency	:25Hz	- 25Hz - 200Hz
Guard time	:99s	- 9s - 99s

The leakage control ensures the safe shutdown of the pump at to higher switching frequency. The function is important for example, To protect submersible pumps from overheating. The switching frequency refers to one hour..

leakage control	:0	- 0-99 per hour
------------------------	----	-----------------

Ensures the safe shutdown of the pump if running too long time. The function is important for example, To protect the pump against leakage.

Select the type of the runtime control.

Runtime control	:0	- 0-999 Min / 0=off
------------------------	----	---------------------

16. adjust messages

messages

IN01-CO-04	: EAS
IN02-CO-05	: WMS
OUT1- 90-91	: ALS
OUT2- 98-N	: VRS
INV1- 01-02	: FAS
INV2- 11-12	: FAS

Password Code: xxx

Parameter: xxx.xx

save: Yes / No



Explanation of parameters:

Digital inputs 1-2: (4, 5)

The digital inputs are adjustable.

external inputs	:xxx	- no function
external inputs	:SOS /SOO	- set point 1+2
external inputs	:Z1S /Z2S	- counter 1/ counter 2
external inputs	:WMS /WMO	- low water
external inputs	:TRS /TRO	- dry run
external inputs	:EAS /EAO	- External on / off
external inputs	:RSS /RSO	- Reset
external inputs	:ESS /ESO	- Extern Störung (also SMS)
external inputs	:FXS /FXO	- Extern Fix frequency Global
external inputs	:HRS /HRO	- Hunter Relay (irrigation)
external inputs	:SIS /SIO	- Main fuse failed
external inputs	:MSS /MSO	- external motor protection (not INV)
external inputs	:SMS /SMO	- low shortage
external inputs	:AKS /AKO	- Battery operation (closer)
external inputs	:SUS / SUO	- Switching main sensor / secondary sensor by Different or Redundant operation
external inputs	:TIS	- Timer set (limit Function)
external inputs	:STS	- Start Pulse Funktion (limit Function)
external inputs	:SRS	- Start/Stop/Reset (limit Function)
external inputs	:SDS	- Start/Stop switch Funktion (limit Function)
external inputs	:SPS	- Start/Stop Pulse Funktion limit Function)
external inputs	:THS	- Thermostat for Bypass (fire mode)
external inputs	:HNS	- Hand refilling, output NSS
external inputs	:ANS	- Auto refilling, output NSS
external inputs	:NSS	- digital request auto refill output NSS
*external inputs	:HPS	- Hand pumping out, output APS
*external inputs	:APS	- Auto pumping out, output APS
external inputs	:NAO	- Emergency stop, shutdown without restart, no SMS reset possible.
external inputs	:P1EP	- Extern Ein/Aus pump 1(intern)
external inputs	:P1WP	- Extern Wassermangel pump 1 (intern)

Digital outputs 1- 2: (90 / 91, 98 / N)

The digital outputs are adjustable.

external outputs	:xxx	- no function
external outputs	:ALO / ALS	- Global Alarm
external outputs	:WMS / WMO	- Wassermangel
external outputs	:TRS / TRO	- dry run
external outputs	:DWS / DWO	- low water Warning (only Auto)
external outputs	:DMS / DMO	- low water
external outputs	:DIS / DIO	- low water Warning (Hand + Auto)
external outputs	:SMS / SMO	- flow shortage
external outputs	:BES / BEO	- operating signal global
external outputs	:ODS / ODO	- maximum value (top value) active
external outputs	:ONS / ONO	- maximum value (top value) Warning
external outputs	:PAS / PAO	- Pumps off
external outputs	:BRS / BRO	- Ready signal global
external outputs	:SES / SEO	- Sensorfehler
external outputs	:HUS / HUO	- Alarm horn; Switch off with reset possible
external outputs	:AKS / AKO	- Battery operation (SMS)

* external outputs :BWS / BWO - Ready signal global + „Wait“

external outputs	:NSS	- refilling (secondary sensor) / (together HRS / ARS)
external outputs	:APS	- pumping out (secondary sensor) / (together HRS / ARS)
external outputs	:BVS	- Bypass valve (temperature switch)

external outputs	:TWS	- Temperature warning secondary sensor
external outputs	:UBS	- Maximum warning secondary sensor

* external outputs	:AFO / AFO	- fire mode Alarm, no Auto Reset
* external outputs	:FAO / FAS	- frequency inverter Alarm



CAUTION ! Change the following settings only after consultation!

external outputs	:HZS	- Heating (cabinet)
external outputs	:VRS	- fan (cabinet) (> 5,4kW INV changeable)
external outputs	:FUS	- release INV 1-x (internal)
external outputs	:PILAS / ALO	- Run signal pump 1 (internal)
external outputs	:PIALS / ALO	- Alarm pump 1 (intern)

Inverter Relays: (INVx) (1 / 2, 11 / 12, 21 / 22))

The alarm relay frequency converter (INV) 1 to frequency converter X is adjustable.
(See frequency converter terminals)

Relay INVx	: xxx	- no function (free setting directly at the INV drive)
Relay INVx	:ALS / ALO	- Local Alarm
Relay INVx	:FAS / FAO	- Global Alarm
Relay INVx	:WMS / WMO	- low water
Relay INVx	:TRS / TRO	- dry run
Relay INVx	:DMS / DMO	- low pressure
Relay INVx	:SMS / SMO	- flow shortage
Relay INVx	:BES / BEO	- operating signal global
Relay INVx	:LAS / LAO	- Run signal per pump
Relay INVx	:ODS / ODO	- maximum value (top value) active

17. adjust communication

Communication

setpoint	: I	setpoint	: P
		Minimum setpoint	: 20%
		Maximum setpoint	: 80%
GSM / users	: A	GSM / users	: A

Password Code: xxx

Parameter: xxx.xx

save: Yes / No



Explanation of parameters:

Select the setpoint specification for the controller.

This function gives you the option of setting the setpoint "I" via keyboard or "P" via a 0-10V signal.

This function is only possible with controllers with frequency converter.

If the secondary sensor is not active, the analog signal "P" from the frequency converter 1 is used with 0-10V.

This function is only possible with controllers with frequency inverters.

setpoint :I - I-internal or secondary transducer / P-potentiometer 0-10V

Enter the limits for the min / max set point range. Within these limits, the potentiometer set point is adjustable.

Attention ! These limits only apply to poti operation!

Minimal setpoint :20% - 0 - 99%

Maximal setpoint :80% - 0 - 99%

Select the GSM function.

This function gives you the possibility to use the GSM function. SMS commands see xx.x.

GSM / users :A - (A) on / (E) off

For a new phone card, enter the PIN.

plant name :
irrigation

plant number :
+49155xxxxxxxxx

user 1 : on
+49150xxxxxxxxx
user 2 : off
+49160xxxxxxxxx
user 3 : off
+49170xxxxxxxxx
user 4 : off
+49177xxxxxxxxx

credit :
*100#

card Contract :
Prepaid

Set the phone book on the SIM - card:

Enter the plants - the names and the facilities - telephone number by one overwrite. With this name, the system reports via SMS.

plant name :irrigation (z.B.)

plant number : +49155123456789 (z.B.)

Switch the user x "On" or "Off" and

Enter the phone number of the user.

If this user is "on" he is entitled to operate the system.

user x : Aus / Ein :+49150123456789 (z.B.)

Change it if necessary free balance inquiry - phone number.

credit : *100# (Germany)

Select the SIM - card Contract.

With this, the SIM card - a management.

SIM - card :Prepaid / contract

18. Setting the Phone Book

To set the system name or phone number, press **SET / RESET button** on the ad. Use the **arrow key ▲ button**, **arrow key ▼ button** and the **SET / RESET button** to change the letters or numbers. After confirming "OK", the change is accepted and the cursor jumps to the next field. To complete the name or phone number you provide a "!" And press "OK".

Now they can use the **arrow key ▼ button** to the next user or go to the end..

All values are only active when they are stored in the "Communication" menu.

Select these characters and numbers in circles: **AB...YZ...ab...yz..._0123456789...+*#...<...!..AB...YZ...**

Special function: ◀ = delete **Special function: ! = finish**

Enter phone number Example:

Station number: Number 1 is selected and confirmed with "OK".
+49**1**

Station number: Number 5 is selected and confirmed with "OK".
+491**5**

Station number: Delete "<" is selected and the number "5" is deleted.
+4915**◀**

Station number: Number 6 is selected and confirmed with "OK".
+491**6**

...
Station number: End "!" Selected to complete the entry
+491621234578**!** and confirm with "OK".

Station number: Entry ended.
+491621234578

Name and other users can be set as well.

Example User Off - On - Switch:

user x : off „OK“
user x : off „OK“
user x : on „▲“ or „▼“
user x : on „OK“


Error Messages GSM "Error Modem"

- 0 = SIM telephone book incomplete. Causes: 1. All "Users" are set to "Off",
2. No valid "User" telephone number is entered
- 1 = SIM lock: Enter PIN
- 2 = Communication between EDS and modem interfered, received murks.
Cause: Interference source or cable damaged?
- 3 = s.o.
- 4 = Problem with SIM card: No SIM inserted?
- 5.6 = Signal strength interrogation (every 10 sec.) Interfered. Cause: Interference source or cable damaged?
- 7 = No response to signal strength query (every 10 sec.): Modem disconnected or off?
- 11 = SMS transmission failed (after 10 attempts).
Causes: 1. Prepaid credit blank, 2nd card blocked at provider, 3. Invalid phone number on SIM
- 12 = Timeout when reading or writing the SIM. One reason: too old and slow SIM or SIM removed?
- 13 = Cable problem (when starting) detected: cable damaged?
- 14 = Error acknowledgment from modem, cause depends on context
- 15 = Communication between EDS and modem interfered, received musks.
Cause: source of interference or cable damaged?
- 16 = Modem in wrong mode. Possible cause: Modem was short-circuit-free. Solution: Re-enable GSM in the menu
- 20 = "ERROR" from the modem when attempting to clean the SIM of SMS. Cause: SIM removed?

19. adjust Internal

Internal

Overheating On	: 65°C
Temperature warning On	: 55°C
Ventilator On	: 35°C
Ventilator Off	: 30°C
Frost warning On	: 03°C
Heating On	: 05°C
Heating Off	: 10°C
frame	: 0
Language	: EN
Dynamic Threshold	: 000%
electronic protection	: 5%
electronic delay	: 30s
Version	: 2
operating hours reset	: 0
Factory reset	: 0
IO Internal	: 0
under-voltage delay	: 30s
Light	: 180s
Display contrast	: 41%
* Save settings	: A
Debug	: 0
* exp.-vessel	: Y



Password Code: xxx

Parameter: xxx.xx

save: Yes / No



Explanation of parameters:

If the values for the control cabinet temperature monitoring. This function protects the cabinet from overheating.

overheating On : 65°C - 55°C - 70°C (99°C=Off)
Temperature warning On : 55°C - 20°C - 60°C

The cabinet fan is at the set temperature and off. This function depends on prior to the frequency line.

Ventilator On : 35°C - 25°C - 35°C
Ventilator Off : 30°C - 20°C - 30°C

If the values for the control cabinet frost monitoring. This function protects the cabinet against frost or condensation.

Frost warning On : 3°C - 0°C - 8°C (9°C = Off)

The cabinet heater is at the set temperature and off. This function depends on prior to installation.

Heating On : 5°C - 1°C - 15°C
Heating Off : 10°C - 6°C - 20°C

To the frame on the display appears around the display foil stick better (active until power "Off").

frame : 0 - 0 (off) / 1 (on)

Set the menu language.

Language : DE / EN / ES - German / English / Spanish

The dynamic threshold is active when the pressure switch operation. Special mode without conservator.

Dynamic Threshold : 0% - 0 - 100%

The electronic protection monitoring for dry running. Special function in target guardian.

electronic protection : 5% - 0 - 50%
electronic delay : 30s - 0 - 99s

Enter the polarity of the DS board.

Version : 2 - 1 / 2

Enter to clear the total hours of the code. (Code: Ask the manufacturer)

operating hours reset : 0 - 0 „Code“

Enter the code to perform a factory reset. (Code: ask the manufacturer)

Factory reset : 0 - 0 „Code“

Enter the code to set the internal I / O menu. (Code: ask the manufacturer)

I/O Internal : 0 - 0 „Code“

Enter the time for the under-voltage delay is to the frequency set to failure.

under-voltage delay :30s - 0 -999s

Enter the time for the display backlight. In setting 0s the light is switched on permanently.

Light (Display) :180s - 0 -999s

This function gives you the possibility to adjust the contrast of the display.

Display contrast :41% - 0 - 99%

The custom settings are saved or loaded.

Save / load settings :A - L(laden) / S(save) / A (Aus)

The MB-debug-S status indicates internal error. There is no setting.

Debug :0 - internal use only

Select whether the system works with or without expansion vessel.

Expansion vessel :Y - no / yes

END Menu

20. Error messages



In the event of a fault, the control switches off and the pump (s) runs free. Error messages are acknowledged by an external external reset input or errors are acknowledged by pressing and holding the SET / REST key. As an option, GMS operation can be reset via SMS.

examples:

Dry-Run	Error Modem	no Network
Hand P1 Er051P2	Dry Run	open Sensor
Error Modbus	low Water	Sensor deviate

Error communication to external devices

The pump controller is connected via a serial connection via Modbus to an external device or the GSM modem.

If the connection is interrupted or disturbed, the pump (s) will not be stopped.

The respective error message appears in the display. The red LED lights up. The alarm relay switches.

Error modem = no connection to GSM modem

Error connection

The pump controller is connected to the frequency converter via a serial Modbus connection.

If the connection is interrupted or disturbed, the respective frequency inverter is stopped.

The display shows the error message "Er101". The red LED lights up. The alarm relay switches.

Error Modbus = no connection to the frequency converter (ER101)

Error transducer

The pump regulator is connected to the sensor via a cable. If the connection is interrupted, the error message "Sensor open" appears. If the connection is disturbed, the error message "Sensor defective" appears.

The respective pump (s) are stopped. The red LED lights up. The alarm relay switches.

Sensor open = Sensor is not connected or faulty. If necessary, press "Reset".

Sensor defective = sensor values are outside the signal values.

Sensor deviation = sensor values are too far apart at Redundant. See menu "Sensor"

Error pressure, switching, U-pump, dry running, lack of water, motor protection

These errors are software shutdowns. Since these are common mistakes, they are displayed in plain text alternating with the error code. The respective pump (s) are stopped. The red LED lights up. The alarm relay switches.

MS = external motor protection tripped. (Operation with softstarter or contactor)

Dry run = shutdown without restart. See the "Security" menu.

Low water = shutdown with restart. See the "Security" menu.

Low pressure = shutdown without restart. See the "Security" menu.

Temperature warning = control cabinet becomes too hot. Improve cooling.

Overheating = the control cabinet becomes too hot. Improve cooling.

PTC = thermistor triggered. Engine too hot.

External alarm = shutdown via an external input. See menu "Messages"

Error messages pump controller with frequency inverter

The error "Er001" to "Er199" are error messages. The red LED lights. The alarm relay switches.

error Er002	: Motor overload (O.C.) Motor protection tripping. Reduce pump power. Adjust motor protection!
error Er003	: Over voltage DC link (O.E.) Mains over voltage; Check check valves. Call service!
error Er004	: Phase error mains input (P.F1) phase failure. Check fuses. Check mains voltage.
error Er005	: Overload converter (O.L1) Inverter Check power; Check pump performance. Set parameters!
error Er006	: Under voltage (L.U.) Mains voltage error. Check fuses, check mains voltage.
error Er007	: Over temperature converter (O.H.) Inverter too hot. Reduce carrier frequency. Cooling defective?
error Er008	: Overload inverter (O.L2) Inverter Check power; Check pump performance. Set parameters!
error Er009	: Under-load inverter (Err)? Engine load too low during operation. Check engine performance?
error Er011	: External error ESP. Enter wrong password on the frequency converter
error Er012	: wrong password Frequency converter (ERR1) Frequency converter defective. Call service!
error Er013	: Error motor parameter ERR2. Set inverter to factory setting! Call service!
error Er014	: Over current at standstill ERR3. Motor load at standstill too high. Pump is blocked! Call service!
error Er015	: Error current measurement ERR4. Frequency converter defective. Exchange the FU. Call service!
error Er016	: Motor overload (OC1) Motor protection tripping. Reduce pump power. Adjust motor protection!
error Er017	: Phase error motor (PF0) Motor phase interrupted. Check motor cable, check engine.
error Er018	: Wire break analog signal (AErr) Set inverter to factory setting! Call service!
error Er019	: Under load inverter (EP3). Engine load too low during operation. Check engine performance?
error Er020	: Under load inverter (EP). Engine load too low during operation. Check engine performance?
error Er021	: Under load inverter (EP2). Engine load too low during operation. Check engine performance?
error Er022	: Sleep mode nP. Set inverter to factory setting! Call service!
error Er023	: Inverter parameter incorrect (ERR5) Set inverter to factory setting! Call service!
error Er026	: Check ground fault in cable or motor or FU (GP) wiring, drive and drive! Call service!
error Er032	: Inverter parameter incorrect (PCE) Set inverter to factory setting! Call service!
error Er035	: Fault PTC thermistor tripping (O.H1). The PTC thermistor has tripped. Improve cooling.
error Er044	: Inverter parameter incorrect (ERR5) Set inverter to factory setting! Call service!
error Er045	: Communication error frequency converter (CE). Modbus address wrong; Check ModBus?
error Er046	: Master - Slave connection faulty (FL). F930 not set correctly. Check keypad setting!
error Er047	: EEPROM error in frequency converter (EEEP) Reset inverter! Call service!
error Er049	: Watchdog error (Em6) Check inverter settings! Call service!
error Er050	: Torque control error (?) Check inverter settings!
error Er053	: Communication error Check keypad (CE1) F930. Check setting on the FI operator part!
error Er067	: Motor overload (OC2) Motor protection tripping. Reduce pump power. Adjust motor protection!

Error messages pump controller

error Er101	: Communication error with the frequency converter Modbus address wrong; Modbus connection defective. Check connection or address
error Er102	: Sensor 1 open. The sensor connection is open. Check cable connection!
error Er103	: Error sensor 1. The sensor value is out of tolerance. .Sensor defect?
error Er104	: Sensor 2 open. The sensor connection is open. Check cable connection!
error Er105	: Error sensor 2. The sensor value is out of tolerance. .Sensor defect?
error Er106	: Error sensor Check deviation between S1 + S2 set tolerance (%). Sensor defect?
error Er107	: Error internal pressure deficiency protection has triggered. Check setting or water inlet!
error Er108	: Error dry running electronically. Dry running protection has triggered .. Check water supply!
error Er109	: Error of external drought protection has triggered. Check setting or water inlet!
error Er110	: Error dry run externally. The external dry run protection has tripped. Check water supply!
error Er111	: Error the set limit pressure has been exceeded. Check system. Set limit pressure!
error Er112	: Error emergency stop (SMS). The plant was set to emergency stop by SMS. Reset only on the system!
error Er113	: Error the set lower limit has fallen below. Check system. Set limit!
error Er114	: External an external error was triggered. Monitoring function for an external system.
error Er115	: Error over temperature control (inverter). The controller gets too hot. Cooling defective?
error Er116	: Enable inverter is missing (software). Dig. Inverter input missing, defective, or not parameterised.
error Er117	: Error modem. An error has occurred during the modem connection. Call service!
error Er118	: Error lack of flow. The flow has fallen below. Check system / flow limit!
error Er119	: Error switching. The switching frequency was exceeded; Clock operation. Check check valves!
error Er120	: Error reaches maximum runtime; Leakage. Run time adjustment, or check check valves.
error Er121	: Error U-pump monitor has tripped. Check water consumption / check valves.
error Er122	: Overheat Cabinet (Warning / Shutdown) .Ventilator Check. Adjust / improve cooling.
error Er123	: Temperature warning Sensor 2 has triggered. The message can be used for frost monitoring.
error Er124	: Fault PTC tripping (software). PTC has tripped. Check engine performance / cooling.
error Er125	: Error PT100 tripping (software). The PT100 has triggered. Check engine performance / cooling.
error Er126	: Error external motor protection. External motor protection tripping. Adjust motor protection!
error Er127	: Failed main fuse failed. External fuse failure. Check main fuse!
error Er128	: Error test run. The test run has not ended without error. Check system!
error Er129	: Battery operation. Battery mode is active. Check power supply!
error Er131	: High level warning when the level is exceeded when the level monitor is functioning.
error Er132	: Enable converter permanently. Dig. Inverter input is on, bridged, or not parameterized.
error Er133-179	: free
error Er190-Er199	: SW-ERR (Call customer service!))

21. Clear memory, change pumps

Reset the daily hours of operation

To the daily operating hours (TLZ) to "0" to reset the following procedure:
Go to the page "operating hours" and hold the SET / RESET button for about 60sec. pressed!

Messages in the display:

OPH Pump 1 1:17:08
DOH Pump 1 1:17:08
...



It appears this message after deleting the display:

OPH Pump 1 1:17:08
DOH Pump 1 0:00:00
...

If unsuccessful, repeat the process.

Reset the fault memory

To reset the fault memory, proceed as follows:
Go to the page "error memory" and hold the SET / RESET button for about 30sec. pressed!

Messages in the display:

ER01 18-01-13 13:59
ER04 19-01-13 11:59
...



It appears this message after deleting the display:

-- ERR1 --
-- ERR2 --
...

If unsuccessful, repeat the process.

pump change

If the pumps are set to "AW" or "PW" in the "Basic" menu, the pump is automatically changed to ensure a smooth operation of the pumps. This pump change is set in the "Controller" menu. The factory setting is 300 operating minutes change time. If a pump is stopped or fails due to a defect, a pump change is performed. If the change time is set to "0", it is changed after each standby.

For service purposes, the pump can be changed by switching off the respective master pump. The stop transfers the master status to the next pump. Now you can proceed in the same way with the new master.

Pumps that are set as jockey, suction pump or boost do not change.

The Jockey pump is the first pump in the system in fixed position with shutdown and transfer to the first system pump. Only possible once. (FU)

The suction pump is the first pump in the system in fixed position only together with one or more system pumps. Running time limitation possible. Only possible once. (Contactor, soft starter)

The booster pump is the last pump with a fixed position system with connection and disconnection. Only possible once. (Contactor, soft starter, FU)

Functions see menu "Basic".

The pump alternation is interrupted by the following criteria:



- The manual mode can be enabled with pump
- The programming process is not completed at a controller
- A pump is at fault.

22. zero flow shut-off

The Zero flow cutoff ensures the safe switching off of the pumps at delivery volume "0" into standby. There are two ways to switch the pumps into standby mode in the MAR regulator.

1. testing phase (T) 50% - 1% - 100% = 0,1 - 1,00bar absolute

The testing phase increases the set point in the function sawtooth whenever a pump is running. The time interval is permanently set in the program. 3 minutes sawtooth, 3 minutes break. By raising the set point, we will put the pump into standby mode at the end of the testing phase with delivery "0". The switch-off frequency is the smallest possible frequency of the pump. The switch-off delay is always active. Only at the last pump does the standby take place after the switch-off delay and the run-on time.

switch-off frequency :35Hz - 1Hz - 200Hz
switch-off delay :2s - 1s - 99s
switch-off frequency :G - global / local

The larger the test phase, the safer the pump will switch to standby mode when pumping "0". This function is called a „life line“.

2. load factor (LF) :50% - 1% - 200% from the frequency inverter
speed factor (DF) :50% - 1% - 100% from the frequency inverter

The second option is to switch the pumps to standby at the "0" level, by setting the load factor and the speed factor for the pump at the set operating point. This function is only possible with frequency inverter operation. On the expert page, the current values for the last pump are visible and the values are set directly. As soon as the pump falls below both values, the last pump with switch-off delay and the switch-off delay is switched to standby. The cut-off frequency is irrelevant.











The logic of mathematical logic is to say:

Actual pressure = set pressure + speed value <+ speed factor load value <= load factor standby.

The load factor and the speed factor can be switched between global and local in the menu. If the factors are local, the two values for each pump can be individually set in the motor menu. This is helpful if the pumps in the system are different sizes.

expert site:

Example: Change of the testing phase (T)

  					  					  				
T 00	LF	00	<u>50</u>	35	T 00	LF	00	50	<u>38</u>	T 00	LF	00	50	38
3.00	DF	00	50		3.00	DF	00	50		3.00	DF	00	50	
P1: 000Hz, 000,0A, 29C P2: 000Hz, 000,0A, 27C					P1: 000Hz, 000,0A, 29C P2: 000Hz, 000,0A, 27C					P1: 000Hz, 000,0A, 29C P2: 000Hz, 000,0A, 27C				
														

After confirming "OK", the change is accepted.

It is possible to combine both zero sets of shutdowns. In 90% of the cases, a setting of the test phase, the cut-off frequency and the switch-off delay will suffice.

Standby :E - (E) on / (A) off

If standby is switched off, the last pump continues to rotate at the cutoff frequency. This feature is used in systems that must maintain a minimum flow.

overrun time :5s - 0s - 999s

The overrun time from the set point is always active at the last pump and adds to the switch-off delay at the last pump. This time is needed because in systems with fixed pumps otherwise no follow-up time would be adjustable.

23. SMS commands

SMS commands the MARH - control mode "pressure, level, temperature":

commands	Send SMS → 📶::
Status query	STATUS
system reset	RESET
Check values	WERTE
delete values	WRESET
Log on the system	ONLINE
Log off the system	OFFLINE
system emergency stop	NOTSTOPP
Start test run	TEST



When an emergency stop is triggered, no SMS reset is possible!
The reset is only possible directly on the controller!

SMS commands the control mode "Pressure control + limit":

commands	Send SMS → 📶::
system start	START
Start system with setpoint 1	START S1
Start system with setpoint 2	START S2
Start system for 40 minutes	START T40
Start system for 40 minutes with setpoint 1	START S1 T40
Start system for 40 minutes with setpoint 2	START S2 T40
stop system	STOPP
system reset and start	RESTART
Status query	STATUS
system reset	RESET
Check values	WERTE
delete values	WRESET
Log on the system	ONLINE
Log off the system	OFFLINE
Start test run	TEST

SMS commands the control mode "+ Adjustable frequency limit":

commands	Send SMS → 📶::
system start	START
system starting with 45Hz	START F45
Start system for 40 minutes	START T40
system starting with 45Hz for 40 minutes	START F45 T40
stop system	STOPP
system reset and start	RESTART
Status query	STATUS
system reset	RESET
Check values	WERTE
delete values	WRESET
Log off the system	ONLINE
Log off the system	OFFLINE
Start test run	TEST


SMS commands the control mode "Soft starter + limit":

commands	Send SMS → 📶::
system start	START
Start system for 40 minutes	START T40
stop system	STOPP
system reset and start	RESTART
Status query	STATUS
system reset	RESET
Check values	WERTE
delete values	WRESET
Log on the system	ONLINE
Log off the system	OFFLINE
Start test run	TEST

24. The standard pressure transducer (Danfoss) MBS:

Transducer 4-20mA with M12x1 connector, 4-pin connection:

Brown (1) 24V = + supply 24VDC (86)
Black (4) = Signal Input 4-20mA (87)



25. customer settings

Date: _____
